



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		48165A 6	REVERSE LOCK VALVE ASSEMB	1		
2	22	45794	ELBOW, HYDRAULIC TRIM HO:	1		
3	22	49719	CONNECTOR, ELBOW	1		
4		45709	FOLLOWER, CAM	1		
5	13	25906	WASHER, WAVE - REVERSE LI	1		
6	25	45710	"O"RING, REVERSE LOCK VAL	1		
7		45526	CAM, REVERSE LOCK VALVE	1		
8	10	46736	SCREW, CAM TO CAM LEVER	1		
9	13	26996	LOCKWASHER, CAM SCREW	1		
10	12	45713	WASHER, RETAINING - BALL T	1		
11	30	45712	BALL, VALVE COVER	30		
12	25	45711	"O" RING, VALVE COVER	1		
13		45528	COVER, REVERSE LOCK VALVE	1		
14	10	45716	SCREW, COVER TO REVERSE	4		
15	11	20110	NUT, COVER SCREW	4		
16	22	21290	PLUG, PIPE - REVERSE LOCK	1		
17		46732A 1	LEVER ASSEMBLY, CAM	1		
18	16	45715	STUD, SHIFT CONTROL LEVE	2		
19		47346	LEVER, SHIFT - CAM LEVER	1		
20	12	21273	WASHER, CAM LEVER STUD	2		
21	11	20110	NUT, SHIFT CONTROL LEVER TC	2		
22	16	34069	STUD, SHIFT CABLE TO SHIFT LI	1		
23	11	20361	NUT, SHIFT CABLE STUD	1		
24	12	39143	WASHER, SHIFT CABLE STUD	3		
25	11	20361	NUT, SHIFT CABLE STUD TO SH	1		
26		27947	SWIVEL, LINK ROD TO SHIFT LE	1		
27		25996A 1	LINK ROD ASSEMBLY	1		
28	11	25168	NUT, JAM - LINK ROD	1		
29		38982	LINK ROD, SHIFT LEVER	1		
30		47459	SWIVEL, LINK ROD TO TRANSMI	1		
31	12	30164	WASHER, LINK ROD SWIVEL	1		
32	11	20110	NUT, LINK ROD SWIVEL	1		
33	10	25299	SCREW, REVERSE LOCK VALVE	2		
34	13	21804	LOCKWASHER, REVERSE LOCK	2		
35		58000A 1	SWITCH ASSEMBLY, CUT-OUT -	1		
36		45717	SHIELD, CUT-OUT SWITCH	1		
37	10	58332	SCREW, SHIELD AND SWITCH T	2		
38	54	54178	"J" CLAMP, CUT-OUT SWITCH LE	1		