


BREAKDOWN OF DISTRIBUTOR



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	392	6316	DISTRIBUTOR (L/H CR/SHAFT R)	1		
1	392	8739	DISTRIBUTOR (R/H CR/SHAFT F)	1		
2	392	9766	CAP DISTRIBUTOR	1		
4	392	9767	ROTOR	1		
5	392	6323	PLATE	1		
6	392	6325	BREAKER	1		
7	392	6324	CONDENSER	1		
9	392	6317	BEARING	1		
10	392	9769	SHAFT	1		
11	392	9770	GEAR AND COLLAR (L/H CR/SI)	1		
11	392	9771	GEAR AND COLLAR (R/H CR/S)	1		
12	392	6333	O-RING (1-1/2" O.D.)	1		
13	392	9088	PRIMARY LEAD	1		