



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		33681A 1	EXHAUST KIT	1		
1	32	33645	HOSE, EXHAUST - ENGINE EXP	4		
2	54	33683	CLAMP, HOSE TO EXHAUST PI	2		
3	32	33685	TUBE, CONNECTOR - EXHAUS	2		
4	54	33683	CLAMP, HOSE TO CONNECTOF	4		
5	54	22875	CLIP, WIRING HARNESS TO BC	2		
6	10	22793	SCREW, WOOD - WIRING HAR	2		
7		22789	"D" WASHER, WIRING HARNE	4		
8		35013	FLANGE, EXHAUST HOSE	2		
9	27	33600	GASKET, EXHAUST HOSE FLA	2		
10	54	33683	CLAMP, HOSE TO EXHAUST FL	2		
11	10	33684	SCREW, EXHAUST HOSE FLAN	6		
12	12	25908	WASHER, EXHAUST HOSE FLA	6		
13	11	20361	NUT, EXHAUST HOSE FLANGE	6		
14		34765A 1	COVER KIT, EXHAUST FLANGE	1		
15	54	33683	CLAMP, COVER TO FLANGE	2		