



| Parts List |       |         |                              |          |              |          |
|------------|-------|---------|------------------------------|----------|--------------|----------|
| Ref        | Class | Part    | Description                  | Qty      | Comment      | Footnote |
| 1          |       | 47805   | TRANSMISSION (DIRECT DRIVE)  | 1,...    |              |          |
| 1          |       | 47806   | TRANSMISSION (1.523:1 REDUCI | ,1,...   |              |          |
| 1          |       | 47807   | TRANSMISSION (1.909:1 REDUC  | ,1,...   |              |          |
| 1          |       | 47808   | TRANSMISSION (2.57:1 REDUC   | ,1,...   |              |          |
| 1          |       | 47809   | TRANSMISSION 2.909:1 REDUC   | ,1,...   |              |          |
| 2          | 10    | 47724   | SCREW, TRANSMISSION TO EN    | 4,...    |              |          |
| 2          | 10    | 47724   | SCREW, TRANSMISSION TO EN    | ,6,6,6,E |              |          |
| 3          | 16    | 45199   | STUD, TRANSMISSION TO EN     | 2,...    |              |          |
| 4          | 13    | 32993   | LOCKWASHER, TRANSMISSION     | 6,6,6,6, |              |          |
| 5          | 11    | 22024   | NUT, TRANSMISSION STUD       | 2,...    |              |          |
| 6          | 22    | 47629   | ELBOW, HOSE TO TRANSMISSI    | 1,1,1,1, |              |          |
| 7          | 32    | 47516 1 | HOSE, OIL COOLER TO TRANSM   | 1,...    |              |          |
| 7          | 32    | 47516 3 | HOSE, OIL COOLER TO TRANSM   | ,1,1,1,1 |              |          |
| 8          | 22    | 47630   | ELBOW, HOSE TO OIL COOLER (  | 1,1,1,1, |              |          |
| 9          |       | 47613   | SWITCH, NEUTRAL SAFETY       | 1,1,1,1, |              |          |
| 10         |       | 48381   | FLANGE (1")                  | OPT.,0   |              |          |
| 10         |       | 48382   | FLANGE (1 1/8")              | OPT.,0   |              |          |
| 10         |       | 48383   | FLANGE (1 1/4")              | OPT.,0   |              |          |
| 10         |       | 48384   | FLANGE (1 3/8")              | OPT.,0   |              |          |
| 10         |       | 48385   | FLANGE (1 1/2")              | OPT.,0   |              |          |
| 11         |       | 47500   | BRACKET, SHIFT CABLE         | 1,...    | NOT AS SHOWN |          |
| 11         |       | 47514   | BRACKET, SHIFT CABLE         | ,1,1,1,1 | NOT AS SHOWN |          |
| 12         | 12    | 22937   | WASHER, SHIFT CABLE TO BRAI  | 1,1,1,1, |              |          |
| 13         | 11    | 20586   | NUT, SHIFT CABLE TO BRACKET  | 1,1,1,1, |              |          |
| 14         | 22    | 47629   | ELBOW, HOSE TO TRANSMISSI    | 1,...    |              |          |
| 15         | 23    | 36159   | BUSHING, REDUCING - TRANSM   | ,1,1,1,1 |              |          |
| 16         | 022   | 47631   | ELBOW, HOSE TO TRANSMISSI    | ,1,1,1,1 |              |          |
| 17         | 32    | 47516 4 | HOSE, TRANSMISSION TO OIL C  | 1,...    |              |          |
| 17         | 32    | 47516 2 | HOSE, TRANSMISSION TO OIL C  | ,1,1,1,1 |              |          |
| 18         | 22    | 47630   | ELBOW, HOSE TO OIL COOLER (  | 1,1,1,1, |              |          |
| 19         |       | 47517   | LEVER, SHIFT - TRANSMISSION  | 1,1,1,1, |              |          |
| 20         | 12    | 20722   | WASHER, SHIFT LEVER TO TRA   | 1,1,1,1, |              |          |
| 21         | 13    | 26993   | LOCKWASHER, SHIFT LEVER TC   | 1,1,1,1, |              |          |
| 22         | 11    | 20083   | NUT, SHIFT LEVER TO TRANSMI  | 1,1,1,1, |              |          |
| 23         |       | 47548   | ADAPTOR, SHIFT CABEL TO SHI  | ,1,1,1,1 |              |          |
| 24         | 13    | 29402   | WAVE WASHER, SHIFT CABLE A   | ,1,1,1,1 |              |          |
| 25         | 12    | 22388   | WASHER, SHIFT CABLE ADAPTC   | ,1,1,1,1 |              |          |
| 26         | 11    | 46438   | NUT, SHIFT CABLE ADAPTOR ST  | ,1,1,1,1 |              |          |
| 27         |       | 47501   | BRACKET, MOUNTING (REAR)     | 2,2,2,2, |              |          |
| 28         | 10    | 47651   | SCREW, MOUNTING BRACKET T    | 4,4,4,4, |              |          |
| 29         | 12    | 22993   | LOCKWASHER, MOUNTING BRA     | 4,4,4,4, |              |          |