


MALLORY



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	391	5071	DISTRIBUTOR ASSEMBLY, COM	1	
1	391	5072	DISTRIBUTOR ASSEMBLY, COM	1	
2	391	5075	CAP, DISTRIBUTOR	1	
2	37	61593	DECAL, DISTRIBUTOR CAP	1	
3	391	5076	GASKET, DISTRIBUTOR CAP	1	
4	391	5088	ROTOR	1	
5	391	5092	CONDENSER	1	
6	391	5093	BRACKET, CONDENSER ATTAC	1	
7	391	5091	SCREW, CONDENSER BRACKE	1	
8	391	5090	BREAKER ASSEMBLY	1	
9	391	5089	SCREW BREAKER, ATTACHING	1	
10	391	5077	LEAD ASSEMBLY, PRIMARY TE	1	
11	391	5085	CLAMP, DISTRIBUTOR CAP AT	2	
12	391	5084	PIN, CLAMP TO DISTRIBUTOR	2	
13	391	5087	SCREW, DISTRIBUTOR CAP ATT	2	
14	391	5086	WASHER, DISTRIBUTOR CAP	2	
15	391	5083	VENT, SCREEN	2	
16	391	5080	OILER	1	
17	391	5078	GEAR, DRIVE (LEFT HAND CRA	1	
17	391	5082	GEAR, DRIVE (RIGHT HAND CF	1	
18	391	5079	PIN, DRIVE GEAR	1	
19	391	5081	"O" RING, DISTRIBUTOR	1	4
20		58258	CLAMP, DISTRIBUTOR TO INTAK	1	
21	10	58259	SCREW, DISTRIBUTOR CLAMP	1	
22	13	58260	LOCKWASHER, DISTRIBUTOR C	1	
23	84	61891	LEAD ASSEMBLY, DISTRIBUTOR	1	
24		26433	COIL, IGNITION	1	
25		33321	BRACKET, IGNITION COIL MOUN	1	
26	10	33311	SCREW, BRACKET TO IGNITION	1	
27	13	35048	LOCKWASHER, BRACKET SCRE	1	
28	12	30164	WASHER, IGNITION COIL TERMI	2	
29	13	26996	LOCKWASHER, IGNITION COIL T	2	
30	11	20645	NUT, IGNITION COIL TERMIAN	2	
31	10	34613	SCREW,IGNITION COIL ATTACHI	1	
32	12	20553	WASHER, IGNITION COIL ATTAC	1	
33	23	60339	SPACER, IGNITION COIL ATTACH	1	
34	84	61801A 4	LEAD ASSEMBLY, HIGH TENSIO	1	
34	84	61801A 7	LEAD ASSEMBLY, HIGH TENSIO	1	
34	84	61801A 3	LEAD ASSEMBLY, HIGH TENSIO	1	
34	84	61801A 6	LEAD ASSEMBLY, HIGH TENSIO	1	
34	84	61801A 2	LEAD ASSEMBLY, HIGH TENSIO	2	