



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		63504A	GIMBAL HOUSING ASSEMBLY/W	1		
1		70862A	GIMBAL HOUSING ASSEMBLY/W	1		
2	16	56296	STUD, GIMBAL HOUSING TO T	2		
3	31	32536	BEARING, ROLLER - GIMBALL I	1		
4	26	32911	OIL SEAL, LOWER GIMBALL HC	1		
5	23	38634	BUSHING, SYNTHANE - GIMBA	1	WITHOUT GIMBAL TRIM SENDE	
6	26	32540	OIL SEAL, UPPER GIMBAL HOL	1	WITHOUT GIMBAL TRIM SENDE	
5	31	21145	ROLLER BEARING, GIMBAL HO	1	WITH GIMBAL TRIM SENDER	
6	26	54925	OIL SEAL, UPPER GIMBAL HOL	1	WITH GIMBAL TRIM SENDER	
7	22	52644	PLUG, PIPE - GIBAL HOUSING	1		
8	22	74036	FITTING, GREASE - GIMBAL HC	2		
8A	19	58934	PLUG, PLASTIC - GIMBALL HO	2		
9		29359	LUBRICAP, GIMBAL HOUSING	2		
10	26	36143	SEAL, GREASE - GIMBAL HOUS	1		
12	30	60794A	BEARING ASSEMBLY, BALL - G	2		
13		61075	TOLERANCE RING, GIMBALL F	1		
14	10	25612	SCREW, DRIVE - GIMBAL HOUS	13		
15	25	20863	"O" RING, GIMBAL HOUSING	1		
16	25	23145	"O" RING, GIMBAL HOUSING	2		
17	16	56766	STUD, HYDRAULIC CONNECTC	2		
18	38	60884	EMBLEM, GIMBAL HOUSING	1	SEE PHOTO FOR CORRECT REI	
19	37	76733	DECAL, GIMBAL HOUSING	1	SEE PHOTO FOR CORRECT REI	
20	17	45212	PIN, SWIVEL - GIMBAL HOUSING	1		
21	18	34212	COTTER PIN, RETAINING - LOWE	1		
22	12	32518	WASHER, GIMBAL HOUSING TO	1		
23		55989A	BOLT ASSEMBLY, ANODIC - GIME	2		
24		55989	ANODIC HEAD, BOLT ASSEMBL	2		
25	12	56085	WASHER, ANODIC BOLT ASSE	2		
26	12	32620	WASHER, GIMBALL HOUSING BC	2		
27		74639	BELLOWS, SHIFT ACTUATING C	1		
28	54	38863	CLAMP, ACTUATING CABLE BEL	1		
29	54	31766	CLAMP, SHIFT ACTUATING CABL	1		
30	12	34567	WASHER, GIMBAL HOUSING STI	2		
31	11	34933	NUT, GIMBAL HOUSING STUD	2		
32	32	60542	TUBE, WATER - GIMBAL HOUSIN	1		
33	23	28055	BUSHING, RUBBER - WATER TU	1		
34		32517	COVER, WATER TUBE SEALING	1		
35	10	28635	SCREW, WATER TUBE SEALING	2		
36	27	65373	GASKET, GIMBAL HSG. TO TRAN	1		
36		65533	SEAL, GIMBAL HSG. TO TRANSO	1		
37	27	47644	GASKET, HYDRAULIC CONNECT	1		