



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		66057A 3	SHIFT BRACKET ASSEMBLY	1	
2	16	79661	STUD, SHIFT CABLE TO BRACK	1	
3	16	73563	STUD, SWITCH ACTUATING AF	1	
4	12	39143	WASHER, SHIFT CABLE TO LEVE	2	
5	11	20361	NUT, SHIFT BRACKET STUD a	2	
6	10	52498	SCREW, SHIFT BRACKET TO FLY	2	
7	12	22248	WASHER, SHIFT BRACKET ATTA	2	
8		76812A 4	REVERSE LOCK VALVE ASSEMB	1	
9	22	45794	ELBOW, HYDRAULIC TRIM HO:	1	
10	22	48167	CONNECTOR, ELBOW	1	
11		45709	FOLLOWER, CAM	1	
12	13	25906	WASHER, WAVE - REVERSE LI	1	
13	25	45710	"O" RING, REVERSE LOCK VAL	1	
14		45526	CAM, REVERSE LOCK VALVE	1	
15	10	46736	SCREW, CAM TO CAM LEVER	1	
16	13	26996	LOCKWASHER, CAM SCREW	1	
17	12	45713	WASHER, RETAINING - BALL T	1	
18	30	45712	BALL, VALVE COVER	30	
19		45528A 2	COVER ASSEMBLY, REVERSE	1	
20	25	45711	"O" RING, VALVE COVER	1	
21	12	59570	WASHER, VALVE COVER	1	
22	10	45716	SCREW, COVER TO REVERSE	4	
23	11	20110	NUT, COVER SCREW	4	
24	22	52644	PLUG, PIPE - REVERSE LOCK V	1	
25		46732A 1	LEVER ASSEMBLY, CAM	1	
26	16	45715	STUD, SHIFT CONTROL LEVE	2	
29	10	25299	SCREW, REVERSE LOCK VALVE	2	
30	13	21804	LOCKWASHER, REVERSE LOCK	2	
31	12	21273	WASHER, CAM LEVER STUD	2	
32	11	20110	NUT, SHIFT CONTROL LEVER TC	2	
33		66397A 1	LEVER ASSEMBLY, SHIFT CONTI	1	
34	16	63081	STUD, SHIFT CABLE TO LEVEF	1	
35	23	31866	SPACER, SHIFT LEVER STUD	1	
36	12	39143	WASHER, SHIFT LEVER STUD	2	
37	11	20361	NUT, SHIFT CABLE TO LEVER :	1	
38	16	63335	STUD, SHIFT CABLE TO SHIFT	1	
40	11	63341	TEE NUT, SHIFT CABLE STUD	1	
41		45517A 2	ARM ASSEMBLY, SWITCH ACTU	1	
42	10	33231	SCREW, TENSION SPRING TO	1	
43	12	26825	WASHER, TENSION SPRING SI	1	
44	24	45599	SPRING, TENSION, SWITCH A	1	