



| Parts List | | | | | | |
|------------|-------|-----------------|-----------------------------------|----------|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| - | | 92497A 3 | ALTERNATOR ASSEMBLY (55 AM | 1 | | |
| 1 | 390 | 7027 | NUT | 1 | | |
| 2 | 390 | 7033 | LOCKWASHER | 1 | | |
| 3 | 390 | 8637 | PULLEY | 1 | | |
| 4 | 390 | 7004 | FAN | 1 | | |
| 5 | | 813969 | SPACER | 1 | | |
| 6 | | 813961 | FRONT HOUSING | 1 | | |
| 7 | 390 | 7005 | BALL BEARING | 2 | | |
| 8 | 10 | 813978A 1 | SCREW | 4 | | |
| 9 | 390 | 7034 | KEY | 1 | | |
| 10 | | 813962 | ROTOR | 1 | | |
| 11 | 390 | 7014 | SLIP RING | 1 | | |
| 12 | | 813963 | STATOR | 1 | | |
| 13 | 390 | 7007 | RETAINER | 1 | | |
| 14 | | 813964 | REAR HOUSING | 1 | | |
| 15 | 10 | 813975 | THRU BOLT | 4 | | |
| 16 | | 813966 | DIODE BRIDGE | 1 | | |
| 17 | | 813965 | DIODE FIELD | 1 | | |
| 18 | 10 | 813981 | SCREW | 3 | | |
| 19 | 11 | 813976 | NUT | 2 | | |
| 20 | | 813973 | STRAP | 1 | | |
| 21 | 390 | 7021 | NUT | 5 | | |
| 22 | | 813971 | COVER | 1 | | |
| 23 | 12 | 813984 | WASHER | 5 | | |
| 24 | 390 | 7022 | WASHER | 2 | | |
| 25 | | 813972 | CAPACITOR | 1 | | |
| 26 | 10 | 813982 | SCREW | 1 | | |
| 27 | 10 | 813979 | SCREW | 2 | | |
| 28 | 10 | 813983 | SCREW | 2 | | |
| 29 | | 813974 | VOLTAGE REGULATOR | 1 | | |
| 30 | 12 | 813985 | WASHER | 2 | | |
| 31 | 11 | 813977 | NUT | 2 | | |
| 32 | 10 | 813980 | SCREW | 8 | | |
| 33 | | 813968 | BRUSH ASSEMBLY | 1 | | |
| 34 | | 813967 | STRAP (D+) | 1 | | |
| 35 | 27 | 813970 | GASKET | 1 | | |