



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		99237A10	SHIFT BRACKET ASSEMBLY	1		
2	16	98798	1 STUD	AR	(2-1/8 IN.)	3
2	16	814002	1 STUD	AR	(2-7/8 IN.)	3
3		13051A	4 ACTUATING LEVER ASSEMBLY	1		
4	24	45599	1 SPRING	1		
5	10	13743	1 SHOULDER SCREW	1		
6	18	32857	1 COTTER PIN	1		
7	24	98880	1 SPRING	1		
8	12	56720	1 WASHER	1		
9	23	814003	1 SPACER (USE WHERE APPLICAE	1		
10	12	35462	3 WASHER	3		
11	11	13438	2 NUT	2		
12	16	96112	1 STUD	1		
13	11	63341	1 TEE NUT	1		
14		13898A	3 SHIFT LEVER ASSEMBLY	1		
15	10	13743	1 SHOULDER SCREW	1		
16	17	814001	1 SHOULDER PIN	1		
17	18	21071	1 COTTER PIN	1		
18		39670A28	1 SWITCH ASSEMBLY	1	(WITH RING TERMINALS)	
18	87	19752A	6 SWITCH ASSEMBLY	1	(WITH BULLET CONNECTORS)	
19	10	30902	2 SCREW	2		
20	86	66986	1 TERMINAL BLOCK	1	USE WHERE APPLICABLE	
21	10	96113	1 SCREW (7/8 IN.)	1	USE WHERE APPLICABLE	
22	10	73287	1 SCREW (3/8 IN.)	1	USE WHERE APPLICABLE	
23	13	26996	2 LOCKWASHER	2	USE WHERE APPLICABLE	
24		813995A	1 SPRING GUIDE ASSEMBLY	1		
25	10	65746	3 SCREW	3	(USE WITH CAST IRON ELBOW)	
26	23	806981	3 SPACER	3	USE WITH STAINLESS STEEL E	
27	12	35462	3 WASHER	3	USE WITH STAINLESS STEEL E	
28	11	64015	3 NUT	3	USE WITH STAINLESS STEEL E	