



19880

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		90747A 3	DISTRIBUTOR ASSEMBLY	1		
2		16457A 4	CAP, DISTRIBUTOR	1		
3	10	90926	SCREW, (10-32 X .81), DISTRIBUTOR	4		
4	27	98242	GASKET, DISTRIBUTOR CAP	1		
5		13524A 3	ROTOR	1		
6		42862	SENSOR WHEEL	1		
7	10	11252	SCREW, (.138-20 x .50), SENSOR WHEEL	3		
8	87	91019A 3	SENSOR ASSEMBLY	1		
9	10	47618	SCREW, (#10-32 X 1.00), SENSOR WHEEL	2		
10	12	27736	WASHER, SENSOR SCREW	2		
11	43	813776 1	GEAR, DRIVE	1		
12	17	47617	PIN, DRIVE GEAR	1		
13	27	34486 3	GASKET, DISTRIBUTOR	1		2
14		52185	CLAMP, DISTRIBUTOR TO INTAKE MANIFOLD	1		
15	10	11976	SCREW, (.375-16 X 1.00), DISTRIBUTOR	1		
17	13	26996	LOCKWASHER, (#10), DISTRIBUTOR	2		
18	11	68219	NUT, (#10-32), DISTRIBUTOR	2		
20	84	813720A 4	SPARK PLUG WIRE KIT (L.H. ROTATION)	1		
20	84	813720A 3	SPARK PLUG WIRE KIT (R.H. ROTATION)	1		
21	85	63709A 1	BOOT/TERMINAL KIT, SPARK PLUG	8		
22	33	59571	SPARK PLUG	8		
23		54676	RETAINER, Two Wire, HIGH TENSILE	2		
24		32783	RETAINER, Three Wire, HIGH TENSILE	2		
25		32784	RETAINER, Four Wire, HIGH TENSILE	2		
26	392	7803A 4	COIL, IGNITION	1		
27		77294	BRACKET, IGNITION COIL	1		
28	10	41408	SCREW, (#10-32 x 1.50), BRACKET	1		
29	12	30164	WASHER, (.192 x .375 x .0312), IGNITION	2		
30	13	26996	LOCKWASHER, (#10), IGNITION	2		
31	11	68219	NUT, (#10-32), IGNITION COIL	2		
32	10	59645	SCREW, IGNITION COIL (3/4")	2		
33	13	39107	LOCKWASHER, (.312), IGNITION	2		
34	12	20084	WASHER, (.328 x .562 x .062), IGNITION	2		
35	16	90096A 1	STUD ASSEMBLY, (#10-32 x Spec)	2		
36	54	72821	RETAINER, WIRE	2		
-	27	75611A88	ENGINE GASKET SET	1		