



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		65604A	EXHAUST MANIFOLD ASSEMBLY	1		
1		65603A	EXHAUST MANIFOLD ASSEMBLY	1		
2	16	49545	STUD, EXHAUST MANIFOLD T	8		
3	22	32802	PLUG, PIPE - EHAUST MANIFO	2		
4	16	49545	STUD, EXHAUST MANIFOLD T	8		
4	16	65947	STUD, EXHAUST MANIFOLD T	8		
5	13	35048	WASHER, EXHAUST MANIFOLD	16		
6	11	49838	NUT, EXHAUST MANIFOLD STI	16		
7	27	73866	GASKET, EXHAUST MANIFOLD T	2		4.2
8	54	54509	EYE, LIFTING - EXHAUST MANIF	2		
9	10	26801	SCREW, LIFTING EYE ATTACHIN	4		
10		60252	END CAP/CONNECTOR, EXHAUS	4		
10		54870	END CAP/CONNECTOR, EXHAUS	2		
11	27	48043	GASKET, END CAP/CONNECTOF	2		2
13	10	25038	SCREW, END CAP ATTACHING (8		
11	27	48043	GASKET, END CAP/CONNECTOF	4		2
12	54	65308	CLIP, HOSE TO MANIFOLD	1		
13	10	35386	SCREW, END CAP/CONNECTOR	12		
13	10	53016	SCREW, END CAP/CONNECTOR	4		
14		60426A	ELBOW ASSY (STERN DI	2	SERIAL 00000000-04497140	
14		76351A	ELBOW ASSY (STERN DI	2	SERIAL 04497141-09999999	
14		60427A	ELBOW ASSY (INBOARD)	2		
15	22	33198	PLUG, EXHAUST ELBOW	8		
16	32	58616A	TUBE, WATER SEPARATION - I	2		
17	22	32802	PLUG, PIPE - EXHAUST ELBOW	2		
18	22	45084	FITTING, EXHAUST ELBOW	2		
19	27	52076	GASKET, EXHAUST ELBOW TO E	4		2
20		60207	PLATE, EXHAUST ELBOW TO EX	2		
21	13	37459	LOCKWASHER, EXHAUST TO EX	8		
22	11	49838	NUT, EXHAUST ELBOW TO EXH	8		