



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		72646	INTKAE MANIFOLD	1		
2	10	26487	BOLT, INTAKE MANIFOLD TO CY	9		
2	10	37510	BOLT, INTAKE MANIFOLD TO CY	3		
3	12	49112	WASHER, INTAKE MANIFOLD BC	3		
4	54	47512	EYE, LIFTING	1		
5	10	34354	SCRE, LIFTING EYE ATTACHING	2		
6	13	35048	LOCKWASHER, LIFTING EYE SCI	2		
7	16	66203	STUD, GUARD TO INTAKE MANII	4		
8		72647	GUARD, INTAKE MANIFOLD	1		
9	27	72637	GASKET SET, INTAKE MANIFOLD	1		
10		60658	WATER PUMP ASSEMBLY	1		4
11	27	34897	GASKET, WATER PUMP MOUN	2		
12	10	52200	SCREW, WATER PUMP TO CYLII	1		3
12	10	32132	SCREW, WATER PUMP TO CYLII	1		
12	10	35346	SCREW, WATER PUMP TO CYLII	1		
12A	16	35342	STUD, WATER PUMP TO CYLINC	1		
13		52349	PULLEY, WATER PUMP	1		
14	10	47277	SCREW, PULLEY TO WATER PU	4		
15	13	39107	LOCKWASHER, WATER PUMP P	4		
16		75420	BALANCER, HARMONIC - CRANK	1		
17		75040	PULLEY, HARMONIC BALANCER	1		
17		33863	PULLEY, HARMONIC BALANCER	1		
18	10	72626	BOLT, PULLEY AND HARMONIC I	1		
19	13	39131	LOCKWASHER, PULLEY AND HA	1		
20	12	35332	WASHER, PULLEY AND HARMOI	1		
21	10	35786	BOLT, CRANKSHAFT PULLEY TO	3		
22	13	35048	LOCKWASHER, CRANKSHAFT PI	3		
23	57	48120	BELT, ALTERNATOR DRIVE (46"	1		
25		35365	SUPPORT, SPARK PLUG LEAD W	2		
26	10	35366	SCREW, LEAD WIRE SUPPORT	2		
27		75612	COVER ASS'Y, CRANKCASE FRC	1		
28	26	59342	OIL SEAL, CRANKCASE FRONT	1		
29	27	34895	GASKET, CRANKCASE FRONT EN	1		3
30	10	34277	SCREW, CRANKCASE FRONT EN	10		
31		75435A	1 POINTER, TIMING	1		
32		53338	FILTER VALVE ASSEMBLY	1		
33	10	54786	SCREW, FILTER VALVE TO CYLII	2		
34		52731	OIL FILTER ASSEMBLY	1		