



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	77441	WIRING HARNESS	1		
2		26079	PLATE, WIRING HARNESS TO M	1		
3		46718	SCREW, WIRING HARNESS PLA	4		
4		77440	BRACKET, MOUNTING - HARNE	1		
5	10	34354	SCREW, MOUNTING BRACKET A	2		
6	13	35048	LOCKWASHER, MOUNTING BRA	2		
7		64884	TAB, WIRING HARNESS	1		
8	89	76416A	STARTER SOLENOID	1		
9	10	69028	SCREW, STARTER SOLENOID TI	2		
11	13	26996	LOCKWASHER, STARTER SOLEI	2		
12	11	68219	NUT, STARTER SOLENOID TERM	2		
13	13	26993	LOCKWASHER, STARTER SOLEI	2		
14	11	68292	NUT, STARTER TERMINAL (5/16	2		
15	88	65093	CIRCUIT BREAKER	1		
--	11	20645	NUT, CIRCUIT BREAKER TERM	2		
--	13	26996	LOCKWASHER, CIRCUIT BREA	2		
16	10	24637	SCREW, CIRCUIT BREAKER TO	2		
17	12	30164	WASHER, CIRCUIT BREAKER SC	2		
18	11	46438	NUT, CIRCUIT BREAKER SCREW	2		
19		45915	TERMINAL BLOCK	1		
20	10	62568	SCREW, TERMINAL BLOCK	1		
20	10	22391	SCREW, TERMINAL BLOCK	1		
21	11	46438	NUT, TERMINAL BLOCK SCREW	1		
22	11	20361	NUT, STARTER SOLENOID SCRE	2		