



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		47551	PANEL, ELECTRIC	1		
2	19	32298	PLUG, ELECTRIC PANEL	2		
3		47763	BRACKET, RETAINER - HIGH TENS	2	EARLY MODELS	
4	25	38930	GROMMET, HIGH TENSION LEAD	2	EARLY MODELS	
5	10	20776	SCREW, RETAINER BRACKET TO	2	EARLY MODELS	
6	13	26392	LOCKWASHER, RETAINER BRAC	2	EARLY MODELS	
7		25661	STARTER SOLENOID	1		
8	13	26393	LOCKWASHER, STARTER SOLE	2		
9	11	20083	NUT, STARTER SOLENOID TERM	2		
10	13	26396	LOCKWASHER, STARTER SOLE	2		
11	11	20645	NUT, STARTER SOLENOID TERM	2		
12	10	26774	SCREW, STARTER SOLENOID T	2		
13	13	26392	LOCKWASHER, STARTER SOLE	2		
14	10	26632	SCREW, ELECTRIC PANEL TO C	1		
15	10	35787	SCREW, ELECTRIC PANEL TO C	1		
16	10	47954	SCREW, ELECTRIC PANEL TO FL	1		
17	13	35048	LOCKWASHER, ELECTRIC PANE	3		
18	12	20553	WASHER, ELECTRIC PANEL SCF	3		
19	25	47624	GROMMET, ELECTRIC PANEL	1		
20	332	2986A 3	SWITCH BOX ASSEMBLY	1		
21	12	45075	WASHER, SWITCH BOX TERMIN	7		
22	13	26396	LOCKWASHER, SWITCH BOX TE	7		
23	11	45076	NUT, SWITCH BOX TERMINAL	7		
24	10	26184	SCREW, SWITCH BOX TO ELECT	4		
25	13	21547	LOCKWASHER, SWITCH BOX SC	4		
26	10	45218	SCREW, GROUND WIRE TO SWI	1		
27		37707	VOLTAGE REGULATOR	1		
28	10	52102	SCREW, VOLTAGE REGULATOR	3		
29	13	26392	LOCKWASHER, VOLTAGE REGU	3		
30		53009A 1	MOUNT ASSEMBLY, SHOCK-VOL	1		
31	10	48004	SCREW, MOUNT TO ELECTRIC	3		
32	10	22421	SCREW, VOLTAGE REGULATO	3		
33	23	27958	SPACER, VOLTAGE REGULATC	3		
34	11	20664	NUT, VOLTAGE REGULATOR S	3		
35	332	2983A 6	IGNITION COIL ASSEMBLY	1		
36	10	45102	SCREW, IGNITION COIL CLAMP	1		
36	10	45103	SCREW, IGNITION COIL CLAMP	1		
37	12	37407	WASHER, IGNITION COIL SCRE	1		
38	54	22740	CLIP, IGNITION LEAD	1		
39		22789	"D" WASHER, IGNITION COIL E	1		
40	11	20645	NUT, IGNITION COIL SCREW	2		