



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		54100A 5	EXHAUST MANIFOLD ASSEMBLY	1	SERIAL 00000000-03838787	
1		54099A 5	EXHAUST MANIFOLD ASSEMBLY	1	SERIAL 00000000-03838787	
2	16	49545	STUD, EXHAUST MANIFOLD TI	8	SERIAL 00000000-03838787	
3	22	48118	PLUG, EXHAUST MANIFOLD	2	SERIAL 00000000-03838787	
4	22	32802	PLUG, PIPE - EXHAUST MANIF	2	SERIAL 00000000-03838787	
5	10	37612	SCREW, EXHAUST MANIFOLD TI	16	SERIAL 00000000-03838787	
6	13	35048	LOCKWASHER, EXHAUST MANIF	16	SERIAL 00000000-03838787	
1		65604A 4	EXHAUST MANIFOLD ASSEMBLY	1	SERIAL 03838788-09999999	
1		65603A 4	EXHAUST MANIFOLD ASSEMBLY	1	SERIAL 03838788-09999999	
2	16	49545	STUD, EXHAUST MANIFOLD TI	8	SERIAL 03838788-09999999	
4	22	32802	PLUG, PIPE - EXHAUST MANIF	2	SERIAL 03838788-09999999	
5A	16	49545	STUD, EXHAUST MANIFOLD TI	8	SERIAL 03838788-09999999	
5A	16	65947	STUD, EXHAUST MANIFOLD TI	8	SERIAL 03838788-09999999	
5B	13	35048	WASHER, EXHAUST MANIFOLD	16	SERIAL 03838788-09999999	
5C	11	49838	NUT, EXHAUST MANIFOLD STI	16	SERIAL 03838788-09999999	
7	27	54566	GASKET, EXHAUST MANIFOLD T	2		4,2
8	54	54509	EYE, LIFTING - EXHAUST MANIF	2		
9	10	27165	SCREW, LIFTING EYE ATTACHIN	4		
10		60252	END CAP/CONNECTOR, EXHAUS	4		
11	27	48043	GASKET, END CAP/CONNECTOR	4		2
12	10	35386	SCREW, END CAP/CONNECTOR	12		
12	10	53016	SCREW, END CAP/CONNECTOR	4		
10		54870	END CAP, EXHAUST MANIFOLD	2	V-DRIVE ONLY	
11	27	48043	GASKET, END CAP TO MANIFOLD	2	V-DRIVE ONLY	2
12	10	25038	SCREW, END CAP TO MANIFOLD	2	V-DRIVE ONLY	
13		60426A 1	EXHAUST ELBOW ASSEMBLY (I	2		
13		60427A 2	EXHAUST ELBOW ASSEMBLY (I	2		
14	22	33198	PLUG, EXHAUST ELBOW	8		
15	32	58616A 1	TUBE, WATER SEPARATION - I	2		
16	22	32802	PLUG, PIPE - EXHAUST ELBO	2		
17	22	45084	FITTING, EXHAUST ELBOW	2		
18	22	62910	FITTING EXHAUST ELBOW STEF	1		
19	32	62987 2	HOSE, EXHAUST ELBOW TO TR	1	STERN DRIVE	
20	54	32523	CLAMP, HOSE ATTACHING STEF	2	STERN DRIVE	
21	27	52076	GASKET, EXHAUST ELBOW TO E	4	STERN DRIVE	2
22		60207	PLATE, EXHAUST ELBOW TO EX	2		
23	13	37459	LOCKWASHER, EXHAUST ELBO	8		
24	11	49838	NUT, EXHAUST ELBOW TO EXH	8		
25		62893	ELBOW, EXHAUST (STARBOARD	1	STERN DRIVE	
25		62892	ELBOW, EXHAUST (PORT SIDE)	1	STERN DRIVE	
26		60920	WATER SHUTTER, EXHAUST EL	2	STERN DRIVE	