



| Parts List | | | | | | |
|------------|-------|-------|-----------------------------|-----|--------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 36368 | HYDRAULIC PUMP ASSEMBLY, F | 1 | | |
| 2 | | 38333 | CAP, FILLER-HYDRAULIC PUMF | 1 | | |
| 3 | 32 | 55117 | HOSE, RETURN-POWER STEERI | 1 | SERIAL 00000000-03415950 | |
| 3 | 32 | 65929 | HOSE, RETURN-POWER STEERI | 1 | SERIAL 03523621-09999999 | |
| 3 | 32 | 65231 | HOSE, RETURN-POWER STEERI | 1 | SERIAL 03523621-09999999 | |
| 4 | 54 | 35830 | CLAMP, HOSE TO HYDRAULIC PI | 3 | | |
| 5 | 32 | 55116 | HOSE, PRESSURE-POWER STEE | 1 | | |
| 6 | | 57969 | CYLINDER, BOOSTER-POWER S | 1 | | |
| 7 | | 26059 | CAP, RUBBER-BOOSTER CYLINC | 1 | | |
| 8 | 32 | 57633 | TUBE, ECTENDING-POWER STE | 1 | STARBOARD MOUNTING | |
| 9 | 32 | 57634 | TUBE, RETRACTING-POWER ST | 1 | STARBOARD MOUNTING | |
| 8 | 32 | 57632 | TUBER, EXTENDING-POWER ST | 1 | PORT MOUNTING | |
| 9 | 32 | 57631 | TUBE, RETRACTING-POWER ST | 1 | PORT MOUNTING | |
| 10 | | 52779 | VALVE, POWER STEERING | 1 | | |
| 10A | 22 | 67305 | FITTING, GREASE-POWER VALV | 1 | | |
| 11 | 16 | 55109 | STUD< ADAPTOR-POWER STEE | 1 | | |
| 12 | 10 | 37961 | 2 SCREW, CLAMPING (1 1/4") | 1 | | |
| 13 | 13 | 37459 | LOCKWASHER, CLAMPING SCRE | 1 | | |
| 14 | 23 | 60652 | SLEEVE, ADJUSTING -CABLE GU | 1 | | |
| 15 | | 57972 | GUIDE, CABLE GUIDE TUBE | 1 | SERIAL 00000000-03415950 | |
| 15 | | 64414 | GUIDE, CABLE GUIDE TUBE | 1 | SERIAL 03523621-09999999 | |
| 16 | 23 | 60773 | SLEEVE, CABLE GUIDE TUBE | 1 | | |
| 17 | | 55110 | ADAPTOR, CABLE GUIDE TUBE (| 1 | | |
| 18 | 13 | 20897 | LOCKWASHER, DUAL ADAPTOR | 1 | | |
| 19 | 11 | 55111 | NUT, DUAL ADAPTOR TO POWE | 1 | | |
| 20 | 32 | 55112 | TUBE, CABLE GUIDE | 1 | | |
| 21 | 12 | 37985 | WASHER, CABLE GUIDE TUB | 1 | | |
| 22 | 11 | 37984 | NUT, CABLE GUIDE TUBE | 1 | | |
| 23 | | 57286 | BRACKET, MOUNTING -TRANSCI | 1 | | |
| 24 | 10 | 31832 | SCREW, MOUNTING BRACKET T | 2 | | |
| 25 | 13 | 31848 | LOCKWASHER, MOUNTING BRA | 2 | | |
| 26 | 10 | 57968 | SCREW, ADJUSTING-MOUNTING | 1 | | |
| 27 | 13 | 37459 | LOCKWASHER, ADJUSTING SCR | 1 | | |
| 28 | 11 | 24883 | NUT, ADJUSTING SCREW | 1 | | |
| 29 | 12 | 20959 | WASHER, VAVLE ADAPTOR STU | 1 | | |
| 30 | 11 | 28040 | NUT, VALVE ADAPTOR STUD | 1 | | |
| 31 | 11 | 32882 | NUT, MOUNTING TUBE | 1 | | |
| 32 | | 57971 | TUBE, MOUNTING-BOOSTER RO | 1 | | |
| 33 | 11 | 55983 | NUT, JAM-MOUNTING TUBE | 1 | | |
| 34 | | 57970 | EXTENSION, CYLINDER BOOSTE | 1 | | |
| 35 | | 66626 | ADAPTOR, ROD END (STARBOA) | 1 | | |