



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		77234A	EXHAUST MANIFOLD ASSEMBLY	1		
1		77235A	EXHAUST MANIFOLD ASSEMBLY	1		
2	16	49545	STUD, EXHAUST MANIFOLD T	8		
3	22	48118	PLUG, EXHAUST MANIFOLD	6		
4	22	32802	PLUG, PIPE - EXHAUST MANIF	2		
5	27	33395	GASKET, EXHAUST MANIFOLD T	2		2
6	10	53728	SCREW, EXHAUST MANIFOLD TI	8		
7		60252	END CAP/CONNECTOR, EXHAUS	4		
8	27	48043	GASKET, END CAP/CONNECTOF	2		2
9	10	24234	SCREW, END CAP TO EXH. MAN	14		
9	10	73657	SCREW, END CAP TO EXH. MAN	2		
10	27	48043	GASKET, END CAP TO EXHAUST	2		2
11		76771A	EXHAUST ELBOW ASSEMBLY	2		
12	22	32802	PLUG, PIPE - EXHAUST ELBOW	2		
13	22	33198A	PLUG, EXHAUST ELBOW	8		
14	27	48042	GASKET, EXHAUST ELBOW TO E	4		2
14	27	52076	GASKET, EXHAUST ELBOW TO E	4		2
15		55730	PLATE, EXHAUST ELBOW TO EX	2		
16	13	35048	LOCKWASHER, EXHAUST ELBO\	8		
17	11	49838	NUT, EXHAUST ELBOW TO EXH	8		
18	222	45084	FITTING, EXH. ELBOW (PART OF	2		