



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		35352	OIL PUMP ASSEMBLY	1		
2	10	48333	BOLT, OIL PUMP TO CYLINDER E	1		
3		35354	SCREEN ASSEMBLY, OIL PUMP	1		
4		36184	SHAFT, OIL PUMP TO DISTRIBU	1		
5	23	36183	RETAINER, OIL PUMP SHAFT	1		
6		52198	BAFFLE, OIL PAN (CYLINDER BLC	1		
7	11	37500	NUT, BAFFLE TO CYLINDER BLO	5		
8		71872A	OIL PAN	1	SERIAL 00000000-05522209	
9	27	85817A	GASKET SET, OIL PAN	1	SERIAL 00000000-05522209	
8		87758A	OIL PAN	1	SERIAL 05522210-09999999	
9	27	90458A	GASKET SET, OIL PAN	1	SERIAL 05522210-09999999	
10	22	87543	PLUG, PIPE - OIL PAN DRAIN	1		
11	10	55714	SCREW, OIL PAN TO BLOCK (5/1	4		
12	13	26993	LOCKWASHER, OIL PAN SCREW	4		
13	10	55715	SCREW, OIL PAN TO BLOCK (1/4	7		
14	13	26992	LOCKWASHER, OIL PAN SCREW	7		
15		86890A	TUBE, OIL LEVEL GAUGE	1		
16	11	47626	NUT, OIL LEVEL GAUGE TUBE	1		
17	22	78039	COUPLING, OIL LEVEL GAUGE	1		
18		87353	GAUGE, OIL LEVEL (DIPSTICK)	1		
19	22	47625	ELBOW, OIL LEVEL GAUGE TUBE	1		
21		87182	BRACKET, OIL LEVEL GAUGE	1		
22	54	47545	CLIP, OIL LEVEL TUBE	1		
23	10	33524	SCREW, CLIP TO BRACKET (5/8"	1		
24	13	39107	LOCKWASHER, CLIP SCREW	1		
25	12	20553	WASHER, OIL LEVEL TUBE BRA	1		
26	11	22053	NUT, CLIP SCREW	1		