



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		76812A 4	REVERSE LOCK VALVE ASSEMB	1		
2		45709	FOLLOWER, CAM	1		
3	22	45794	ELBOW, HYDRAULIC TRIM HO:	1		
4	22	48167	CONNECTORM ELBOW	1		
5	22	52644	PLUG, PIPE-REVERSE LOCK VA	1		
6	13	25906	WASHER, WAVE-REVERSE LO	1		
7	25	45710	"O" RING, REVERSE LOCK VAL	1		
8		45526	CAM, REVERSE LOCK VALVE	1		
9	10	46736	SCREW, CAM TO CAM LEVER (1		
10	13	26996	LOCKWASHER, CAM SCREW	1		
11		45528A 2	COVER ASSEMBLY, REVERSE	1		
11A	12	59570	WASHER, REVERSE LOCK VA	1		
12	25	45711	"O" RING, VALVE COVER	1		
13	30	45712	BALL, VALVE COVER	30		
14	12	45713	WASHER, REATINING-BALL TC	1		
15	10	45716	SCREW, COVER TO REVERSE	4		
16	11	20110	NUT, COVER SCREW	4		
17		46732A 1	EMBLY, CAM	1		
18	16	45715	STUD, SHIFT CONTROL LEVE	2		
19	10	25299	SCREW, REVERSE LOCK VALV	2		
20	13	21804	LOCKWASHER, REVERSE LOCK	2		
21		66397A 1	LEVER ASSEMBLY, SHIFT CONTI	1		
22	12	21273	WASHER, CAM LEVER STUD	2		
23	11	20110	NUT, SHIFT CONTROL LEVER TC	2		