



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	52951A	TUBING, HYDRAULIC PUMP TO V	1		
1	32	58432A	TUBING, HYDRAULIC PUMP TO V	1		
2	22	49718	NUT, COMPRESSION-HYDRAULI	2		
3	32	55816	HOSE, HYDRAULIC-CONNECTOF	1		
3	32	59841	HOSE, HYDRAULIC-CONNECTOF	1		
4	32	59842	HOSE, HYDRAULIC-CONNECTOF	1		
5	32	86036	HOSE, HYDRAULIC-CONNECTOF	4		
6		45706A	14 TRIM CYLINDER ASSEMBLY, COI	2	SEE NEXT PAGE FOR REPAIR F	
-		45522A	3 PIVOT END REPAIR KIT, TRIM	2	SEE NEXT PAGE FOR REPAIR F	
-		77442A	1 OUTER TUBE REPAIR KIT, TRI	2	SEE NEXT PAGE FOR REPAIR F	
-	25	60342A	2 "O" RING REPAIR KIT, TRIM CY	2	SEE NEXT PAGE FOR REPAIR F	
7	17	45735	PIN, FRONT ANCHOR-TRIM CYLI	1		
8	12	45737	WASHER, FRONT ANCHOR PIN	2		
9	32	89574	BUSHING, RUBBER-FRONT ANCI	4		
10	24	46312	SPRING, FRONT ANCHOR PIN	2		
11	12	46765	WASHER, FRONT ANCHOR PIN	2		
12	11	34932	NUT, FRONT ANCHOR PIN	2		
13	17	45738	PIN, REAR ANCHOR-TRIM CYLIN	1		
14	12	45737	WASHER, REAR ANCHOR PIN	2		
15	23	89574	BUSHING, RUBBER-REAR ANCH	4		
16	12	46765	WASHER, RAER ANCHOR PIN	2		
17	11	34932	NUT, REAR ANCHOR PIN	2		
--	24	86687A	1 SPRING CONTINUINTY KIT	1		