



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	735	6370	PISTON AND PISTON PIN ASSEM	AR		
1	735	6371	PISTON AND PISTON PIN ASSEM	AR		
2	39	65153	RING, PISTON - 8 SETS (STANDA	8		
2	39	67126	RING, PISTON - 8 SETS (.030 O.S	AR		
3	23	85694	BEARING UNIT, CRANKSHAFT M	4		
3	23	85695	BEARING UNIT, CRANKSHAFT M	AR		
3	23	85696	BEARING UNIT, CRANKSHAFT M	AR		
3	23	85697	BEARING UNIT, CRANKSHAFT M	AR		
4	23	85698	BEARING UNIT, CRANKSHAFT M	1		
4	23	85699	BEARING UNIT, CRANKSHAFT M	AR		
4	23	85700	BEARING UNIT, CRANKSHAFT M	AR		
4	23	52216	BEARING UNIT, CRANKSHAFT M	AR		
5	17	24813	PIN, DOWEL - REAR CRANKSHA	1		
6	26	58203	OIL SEAL, REAR CRANKSHAFT B	2		
10	10	54788	BOLT, CRANKSHAFT BEARING C	5		
11	16	54790	STUD, CRANKSHAFT BEARING C	5		
--	17	24813	PIN, DOWEL - CRANKCASE FRO	4		
12	222	6355	FLYWHEEL ASSEMBLY	1		
13	13	39131	LOCKWASHER, FLYWHEEL SCRI	6		
14	10	49845	SCREW, FLYWHEEL TO CRANKE	6		
15	614	3595	CONNECTING ROD ASSEMBLY (C	8	SERIAL 00000000-05500136	
15	614	8164	CONNECTING ROD ASSEMBLY (C	8	SERIAL 05500137-09999999	
16	10	85802	BOLT, CONNECTING ROD CAP	16		
17	11	37493	NUT, CONNECTING ROD CAP E	16		
18	23	85701	BEARING SET (PAIR), CONNECTI	8		
18	23	85702	BEARING UNIT (PAIR), CONNECT	AR		
18	23	85703	BEARING UNIT (PAIR), CONNECT	AR		
18	23	85704	BEARING UNIT (PAIR), CONNECT	AR		
18	23	85705	BEARING UNIT (PAIR), CONNECT	AR		
19	43	48338	SPROCKET, CRANKSHAFT TIMIN	1		8
20	429	6369	CRANKSHAFT	1		
21	28	34466	KEY, CRANKSHAFT PULLEY AND	2		
23		76850A 2	ENGINE COUPLING ASSEMBLY	1		
24	16	32808	STUD, COUPLING TO FLYWHEEL	6		
25	12	34567	WASHER, COUPLING STUD	6		
26	11	98533	NUT, COUPLING STUD	6		