



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		94912A3	SHIFT PLATE ASSEMBLY	1	
2	16	79661	STUD, SHIFT CABLE	1	
3	16	73563	STUD, ACTUATING SWITCH	1	
4	12	39143	WASHER, SHIFT CABLE STUD	2	
5	23	31866	SPACER, SHIFT CABLE STUD	1	
6	11	20361	NUT, SHIFT CABLE STUD	1	
7	12	26825	WASHER, ACTUATING AIM STU	2	
8	23	37981	SPACER, ACTUATING AIM STUD	1	
9		45517A 2	ARM ASSEMBLY, SWITCH ACTU	1	
10	23	45600	SLEEVE, SWITCH ACTUATING	1	
11	24	45599	SPRING, TENSION	1	
12	10	33231	SCREW, TENSION SPRING	1	
13	12	26825	WASHER, TENSION SPRING SI	1	
14	18	32857	COTTER PIN, SHIFT CABLE	1	
15	11	35814	NUT, ACTUATING ARM STUD	1	
16	86	66986	TERMINAL BLOCK	1	
17	10	24637	SCREW, TERMINAL BLOCK (7/8"	1	
17	10	45218	SCREW, TERMINAL BLOCK (3/8"	1	
18		39670A28	SWITCH ASSEMBLY, ACTUATING	1	
19	10	30902	SCREW, ACTUATING SWITCH	2	
20	10	35047	SCREW, SHIFT PLATE	1	
21	12	34931	WASHER, SHIFT PLATE SCREW	1	
22		76812A 4	REVERSE LOCK VALVE ASSEMB	1	
23		45709	FOLLOWER, CAM	1	
24	22	45794	ELBOW, REVERSE LOCK VALV	1	
25	22	49719	CONNECTOR, ELBOW	1	
26	22	52644	PIPE PLUG, REVERSE LOCK VA	1	
27	13	25906	WAVE WASHER, REVERSE LO	1	
28	25	45710	"O" RING, REVERSE LOCK VAL	1	
29		45526	CAM, REVERSE LOCK VALVE	1	
30	10	46736	SCREW, CAM TO CAM LEVER (1	
31	13	26996	LOCKWASHER, CAM SCREW	1	
32		45528A 2	COVER ASSEMBLY, REVERSE	1	
33	12	59570	WASHER, REVERSE LOCK VA	1	
34	25	45711	"O" RING, VALVE COVER	1	
35	30	45712	BALL, VALVE COVER	30	
36	12	45713	WASHER, RETAINING - BALL T	1	
37	10	45716	SCREW, COVER TO REVERSE	4	
38	11	20110	NUT, COVER SCREW	4	
39		46732A 1	LEVER ASSEMBLY, CAM	1	
40	16	45715	STUD, SHIFT CONTROL LEV	2	