



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		99237A10	SHIFT BRACKET ASSEMBLY	1		
2	16	98798 1	STUD	AR	(2-1/8 IN.)	3
2	16	814002 1	STUD	AR	(2-7/8 IN.)	3
3		13051A 4	ACTUATING LEVER ASSEMBLY	1		
4	24	45599	SPRING	1		
5	10	13743	SHOULDER SCREW	1		
6	18	32857	COTTER PIN	1		
7	24	98880	SPRING	1		
8	12	56720	WASHER	1		
9	23	814003	SPACER (USE WHERE APPLICAE	1		
10	12	35462	WASHER	3		
11	11	13438	NUT	2		
12	16	96112	STUD	1		
13	11	63341	TEE NUT	1		
14		13898A 3	SHIFT LEVER ASSEMBLY	1		
15	10	13743	SHOULDER SCREW	1		
16	17	814001	SHOULDER PIN	1		
17	18	21071	COTTER PIN	1		
18		39670A28	SWITCH ASSEMBLY	1	(WITH RING TERMINALS)	
18	87	19752A 6	SWITCH ASSEMBLY	1	(WITH BULLET CONNECTORS)	
19	10	30902	SCREW	2		
20	86	66986	TERMINAL BLOCK	1	USE WHERE APPLICABLE	
21	10	96113	SCREW (7/8 IN.)	1	USE WHERE APPLICABLE	
22	10	73287	SCREW (3/8 IN.)	1	USE WHERE APPLICABLE	
23	13	26996	LOCKWASHER	2	USE WHERE APPLICABLE	
24		813995A 1	SPRING GUIDE ASSEMBLY	1		
25	10	65746 1	SCREW	3	(USE WITH CAST IRON ELBOW)	
26	23	806981	SPACER	3	USE WITH STAINLESS STEEL E	
27	12	35462	WASHER	3	USE WITH STAINLESS STEEL E	
28	11	64015	NUT	3	USE WITH STAINLESS STEEL E	