

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		44187A 1	HOUSING, FLYWHEEL	1		
1A	19	12304	PLUG, TIMING WINDOW	1		
2		14043A 5	COVER ASSEMBLY, FLYWHEEL H	1		
3		87690	SEAL, FLYWHEEL HOUSING CO	1		
4	27	86015	GASKET, FLYWHEEL HOUSING	1		
5	10	98253	SCREW, COVER TO FLYWHEEL HI	8		
6	13	26992	LOCKWASHER, COVER SCREW	8		
7	10	34353	SCREW, FLYWHEEL HOUSING (1	2		
7	10	47688	SCREW, FLYWHEEL HOUSING (2	2		
7	10	47462	SCREW, FLYWHEEL HOUSING (1	2		
8	13	35048	LOCKWASHER, FLYWHEEL HOU	7		
9	54	78945	"J" CLAMP, FLYWHEEL HOUSING	2		
10	16	64066	STUD, FLYWHEEL HOUSING (2-1	2		
11	12	20572	WASHER, FLYWHEEL HOUSING	2		
12	11	32219	NUT, FLYWHEEL HOUSING STUI	2		

