



19893

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		17618	INTAKE MANIFOLD	1		
2	10	11976	SCREW, (.375-16 X 1.00), INTAKE	9		
2		N.S.S.	Not Sold Seperate, BOLT-INTAKE	3		
3		75435A 1	POINTER, TIMING	1		
4	54	47512	LIFTING EYE	1		
5	10	34354	SCREW, (.375-16 x 1.50), LIFTING	2		
6		N.S.S.	Not Sold Seperate, STUD-GUARD	4		
7		72647	GUARD, INTAKE MANIFOLD	1		
8	27	17145	GASKET SET, INTAKE MANIFOLD	1		2
9		17437	WATER PUMP ASSEMBLY	1		
10	27	34897	GASKET, WATER PUMP MOUNT	2		2
11	10	32132	SCREW, (.375-16 x 1.750), WATER	2		
11	10	47688	SCREW, (.375-16 x 2.750), WATER	1		
11	10	52200	SCREW, WATER PUMP TO CYLIND	1		
12		15120T	PULLEY, WATER PUMP	1	(5.50 Inch Diameter)	
12		19692T	PULLEY, WATER PUMP	1	(7 Inch Diameter)	
13	10	47277	SCREW, (.312-24 x .750), PULLEY	4		
14	13	39107	LOCKWASHER, (.312), WATER PI	4		
15		75420	BALANCER, HARMONIC - CRANK	1		
16		90081T 1	PULLEY, HARMONIC BALANCER	1		
17	57	49213A 1	BELT (44")	1	(Use with 5.50 Inch Diameter Pulley	
17	57	48120A 1	V BELT (46")	1	(Use with 7 Inch Diameter Pulley)	
18	10	32515	SCREW, (.437-20 x 2.50), PULLEY	1		
19	13	39131	LOCKWASHER, (.437), PULLEY A	1		
20	12	35332	WASHER, PULLEY AND HARMONIC	1		
21	10	53833	BOLT, (.375-24 X 2.00), PULLEY	3		
22	13	35048	LOCKWASHER, (.375), PULLEY B	3		
23	12	34714	WASHER, PULLEY BOLT	3		
24	23	35365	SUPPORT, SPARK PLUG LEAD W	2		
25	10	35366	SCREW, (.250-20 x .563), LEAD W	2		
26		14249A 2	COVER, CRANKCASE FRONT	1		
27	26	97335	SEAL, OIL - COVER	1		2
28	27	14250	GASKET, COVER	1		2
29	10	35366	SCREW, (.250-20 x .563), COVER	10		
30		14239	RETAINER, OIL SEAL (REAR) L.H	1		
31	26	14240	OIL SEAL, CRANKSHAFT (REAR)	1		2
30		15122	RETAINER, OIL SEAL (REAR) R.F	1		
31	26	15123	OIL SEAL, CRANKSHAFT (REAR)	1		2
32	27	14241	GASKET, OIL SEAL RETAINER	1		2
33	10	14243	BOLT, (.250-20 x 1.750), OIL SEAL	1		
34	10	14242	BOLT, (.250-20 x .875), OIL SEAL	2		