


SERIAL NO. 4499391 AND UP



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		74905A 3	DISTRIBUTOR ASSEMBLY, COM	1	
2	391	5075	CAP, DISTRIBUTOR	1	
3	391	6389	GASKET, DISTRIBUTOR CAP	1	
4	391	5088	ROTOR	1	
5	391	5092	CONDENSER	1	
6	391	5093	BRACKET, CONDENSER ATTACH	1	
7	391	5091	SCREW, CONDENSER BRACKET	1	
8	391	5090	BREAKER ASSEMBLY	1	
9	391	5089	SCREW, BREAKER ATTACHING	1	
10	84	65773A 6	LEAD ASSEMBLY, PRIMARY TER	1	
11	391	5085	CLAMP, DISTRIBUTOR CAP AT	2	
12	391	5084	PIN, CLAMP TO DISTRIBUTOR	2	
13	391	5087	SCREW, DISTRIBUTOR CAP AT	2	
14	391	5086	WASHER, DISTRIBUTOR CAP S	2	
15	391	5083	VENT, SCREEN	2	
16	391	5080	OILER	2	
17	391	6390	GEAR, DRIVE	1	
18	391	6391	PIN, DRIVE GEAR	1	
19	27	52184	GASKET, DISTRIBUTOR	1	4
20		52185	CLAMP, DISTRIBUTOR TO INTAK	1	
21	10	54528	SCREW, DISTRIBUTOR TO CLAM	1	
22	84	75901	LEAD ASSEMBLY, DISTRIBUTOR	1	
23		26433	COIL, IGNITION - DELCO REMY - C	1	DO NOT MIX WITH PRESTOLITE
24		34106	BRACKET, IGNITION COIL MOUN	1	DO NOT MIX WITH PRESTOLITE
25	10	33311	SCREW, COIL TO BRACKET (1 1/	1	DO NOT MIX WITH PRESTOLITE
23		32193	COIL, IGNITION - PRESTOLITE	1	DO NOT MIX WITH DELCO REM
24		77294	BRACKET, IGNITION COIL MOUN	1	DO NOT MIX WITH DELCO REM
25	10	66652	SCREW, COIL TO BRACKET (1 1/	1	DO NOT MIX WITH DELCO REM
26	12	30164	WASHER, IGNITION COIL TERMI	2	
27	13	26996	LOCKWASHER, IGNITION COIL T	2	
28	11	68219	NUT, IGNITION COIL TERMINAL	2	
29	10	25299	SCREW, IGNITION COIL ATTACH	2	
30	12	20084	WASHER, IGNITION COIL ATTAC	2	
31	13	26993	LOCKWASHER, IGNITION COIL A	2	
32	84	67957 5	LEAD ASSEMBLY, HIGH TENSIO	1	
32	84	67957 8	LEAD ASSEMBLY, HIGH TENSIO	1	
32	84	67957 4	LEAD ASSEMBLY, HIGH TENSIO	1	
32	84	67957 1	LEAD ASSEMBLY, HIGH TENSIO	1	
32	84	67957 10	LEAD ASSEMBLY, HIGH TENSIO	2	
32	84	67957 7	LEAD ASSEMBLY, HIGH TENSIO	1	
32	84	67957 11	LEAD ASSEMBLY, HIGH TENSIO	1	