



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		72646	INTAKE MANIFOLD	1		
2	10	26487	BOLT, INTAKE MANIFOLD TO CY	9		
2	10	37510	BOLT, INTAKE MANIFOLD TO CY	9		
3	12	49112	WASHER, INTAKE MANIFOLD BC	3		
4	54	47512	EYE, LIFTING	1		
5	10	34354	SCREW, LIFTING EYE ATTACHIN	2		
6	13	35048	LOCKWASHER, LIFING EYE SCR	2		
7	16	66203	STUD, GUARD TO INTAKE MANII	4		
8		72647	GUARD, INTAKE MANIFOLD	1		
9	27	72637	GASKET SET, INTAKE MANIFOLC	1		6,4
10		60658	WATER PUMP ASSEMBLY	1		
11	27	34897	GASKET, WATER PUMP MOUN	2		5
12	10	48424	SCREW, WATER PUMP TO CYLI	3		
12	10	47688	SCREW, WATER PUMP TO CYLI	1		
13		52349	PULLEY, WATER PUMP	1		
14	10	47277	SCREW, PULLEY TO WATER PU	4		
15	13	39107	LOCKWASHER, WATER PUMP P	4		
16		72650	BALANCER, HARMONIC - CRANK	1		
17		33863	PULLEY, HARMONIC BALANCE	1	WITHOUT POWER STEERING	
18	10	72626	BOLT, PULLEY AND HARMONIC	1		
19	13	39131	LOCKWASHER, PULLEY AND HA	1		
20	12	35332	WASHER, PULLEY AND HARMO	1		
21	10	34352	BOLT, CRANKSHAFT PULLEY TO	3	WITHOUT POWER STEERING	
22	13	35048	LOCKWASHER, CRANKSHAFT PI	3	WITHOUT POWER STEERING	
23	57	48120	BELT, ALTERNATOR DRIVE (46"	1		
24	842	5941	CYLINDER BLOCK ASSEMBLY	1	SEE CYLINDER BLOCK AND PIS	
25		35365	SUPPORT, SPARK PLUG LEAD W	2		
26	10	35366	SCREW, LEAD WIRE SUPPORT	2		
27		72648	COVER ASSEMBLY, CRANKCASE	1	SERIAL 00000000-04625709	
27		75612	COVER ASSEMBLY, CRANKCASE	1	SERIAL 04625710-09999999	
28	26	59342	OIL SEAL, CRANKCASE FRONT	1		
29	27	34895	GASKET, CRANKCASE FRONT EI	1		5
30	10	34277	SCREW, CRANKCASE FRONT EN	10		
31		60661	POINTER, TIMING	1		
32		53338	FILTER VALVE ASSEMBLY	1		
33	10	36404	SCREW, FILTER VALVE TO CYLI	2	SERIAL 00000000-04499390	
33	10	54786	SCREW, FILTER VALVE TO CYLI	2	SERIAL 04499391-09999999	
34		52731	OIL FILTER ASSEMBLY	1		