



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	50	99417A 2	STARTER MOTOR ASSEMBLY	1	
1		71696	HOUSING	1	
2	23	33369	BUSHING	1	
3		814474	COLLAR	1	
4	53	33290	RING	1	
5		33291	COLLAR	1	
6		79205	DRIVE ASSEMBLY	1	
7		N.S.S.	BEARING PLATE (DELCO-REMY)	1	
8	23	71694	BUSHING	1	
9	12	68614	WASHER	1	
10	10	79209	SCREW	2	
11		75665	ARMATURE	1	
12		N.S.S.	POLE SHOE (DELCO-REMY #81	4	
13		N.S.S.	SCREW (DELCO-REMY #19683	4	
14	25	79208	GROMMET	1	
15		75664	FIELD COIL ASSEMBLY	1	
16	12	33258	LEATHER WASHER	1	
17		79211	FRAME	1	
18		N.S.S.	THRU BOLT (DELCO-REMY #19	1	
18		N.S.S.	THRU BOLT (W/EXTENSION D	1	
19		33284	HOLDER	2	
20		33283	HOLDER	2	
21		33270	BRUSH	4	
22		N.S.S.	SCREW (DELCO-REMY #44352	2	
23		33294	SUPPORT PACKAGE	2	
24	24	33285	SPRING	4	
25		N.S.S.	DOWEL PIN (DELCO-REMY #8C	1	
26		71698	SHIFT LEVER	1	
27		N.S.S.	PIN (DELCO-REMY #1945804)	1	
28	53	33354	RETAINING RING	1	
29		N.S.S.	PLUNGER (DELCO-REMY #197	1	
30	17	79207	PIN	1	
31		N.S.S.	SPRING (DELCO-REMY#19782	1	
32		N.S.S.	SCREW (DELCO-REMY #94132)	2	
33	89	18080	SOLENOID SWITCH (3-5/8" LO	1	