



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		85374A 3	DISTRIBUTOR ASSEMBLY, COM	1		
2	43	73579 1	DRIVE GEAR	1		
3	17	29077	ROLL PIN, DISTRIBUTOR GEAR	1		
4	26	58219	SEAL, HOUSING	1		
5		33653	FELT, LUBRICATOR	2		
6		72654	RETAINER, LUBRICATOR FELT	1		
7		33662	CONDENSER	1		
8		48024	BRACKET, CONDENSER	1		
9	10	48021	SCREW, CONDENSER BRACKET	1		
10		34235	BREAKER	1		
11	10	33650	SCREW, BREAKER	1		
12	25	33666	GROMMET, PRIMARY WIRE	1		
13		33658	LEAD, PRIMARY	1		
14		58217	ROTOR	1		
15	393	9459	DISTRIBUTOR CAP	1		
16	24	73642	SPRING, DISTRIBUTOR SHAFT	1		
17	53	73499	LOCK RING, DISTRIBUTOR SHAFT	1		
18		73501	DRIVE SHAFT, DISTRIBUTOR	1		
19	27	34486 3	GASKET, DISTRIBUTOR	1		2
20	84	813720A 6	SPARK PLUG WIRE KIT	1		
21	33	97389	SPARK PLUG	4		
22		54676	RETAINER, HIGH TENSION LEAD	1		
23	54	72821	CLAMP, HIGH TENSION LEADS	1		
24	16	73583	STUD, HIGH TENSION LEAD CLAMP	1		
26		32193A 2	COIL, IGNITION	1		
27		65970	BRACKET, IGNITION COIL	1		
28	10	41408	SCREW, BRACKET TO COIL	1		
29	10	35386	SCREW, IGNITION COIL TO CYLINDER	1		
30	12	20084	WASHER, IGNITION COIL SCREW	1		
31	12	30164	WASHER, IGNITION COIL TERMINAL	2		
32	13	26996	LOCKWASHER, IGNITION COIL TERMINAL	2		
33	11	68219	NUT, IGNITION COIL TERMINAL	2		
34		67511	CLAMP UNIT, DISTRIBUTOR	1		
35	10	35386	SCREW, DISTRIBUTOR TO BLOCK	1		
36	13	26993	LOCKWASHER, DISTRIBUTOR TO BLOCK	1		