



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		85374A 3	DISTRIBUTOR ASSEMBLY, COM	1	
2	43	73579 1	DRIVE GEAR	1	
3	17	29077	ROLL PIN, DISTRIBUTOR GEAR	1	
4	26	58219	SEAL, HOUSING	1	
5		33653	FELT, LUBRICATOR	2	
6		72654	RETAINER, LUBRICATOR FELT	1	
7		33662	CONDENSER	1	
8		48024	BRACKET, CONDENSER	1	
9	10	48021	SCREW, CONDENSER BRACKET	1	
10		34235	BREAKER	1	
11	10	33650	SCREW, BREAKER	1	
12	25	33666	GROMMET, PRIMARY WIRE	1	
13		33658	LEAD, PRIMARY	1	
14		58217	ROTOR	1	
15	393	9459	DISTRIBUTOR CAP	1	
16	24	73642	SPRING, DISTRIBUTOR SHAFT	1	
17	53	73499	LOCK RING, DISTRIBUTOR SHAFT	1	
18		73501	DRIVE SHAFT, DISTRIBUTOR	1	
19	27	34486 3	GASKET, DISTRIBUTOR	1	2
20	84	813720A 6	SPARK PLUG WIRE KIT	1	
21	33	97389	SPARK PLUG	4	
22		54676	RETAINER, HIGH TENSION LEAD	1	
23	54	72821	CLAMP, HIGH TENSION LEADS	1	
24	16	73583	STUD, HIGH TENSION LEAD CLAMP	1	
26		32193A 2	COIL, IGNITION	1	
27		65970	BRACKET, IGNITION COIL	1	
28	10	41408	SCREW, BRACKET TO COIL	1	
29	10	35386	SCREW, IGNITION COIL TO CYLINDER	1	
30	12	20084	WASHER, IGNITION COIL SCREW	1	
31	12	30164	WASHER, IGNITION COIL TERMINAL	2	
32	13	26996	LOCKWASHER, IGNITION COIL TERMINAL	2	
33	11	68219	NUT, IGNITION COIL TERMINAL	2	
34		67511	CLAMP UNIT, DISTRIBUTOR	1	
35	10	35386	SCREW, DISTRIBUTOR TO BLOCK	1	
36	13	26993	LOCKWASHER, DISTRIBUTOR TO BLOCK	1	