



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		44393A 2	BRACKET, OIL FILTER	1		
2		32720	ADAPTOR	1		
3	27	91892	GASKET, ADAPTOR COVER AND	2		1
4		14957	OIL FILTER	1		
5		90783A22	ADAPTOR ASSEMBLY, OIL FILTE	1		
6		99889	VALVE, BY-PASS	1		
7		32720	ADAPTOR	1		
8	27	99893	GASKET, OIL FILTER ADAPTOR	1		1
9	10	91966	SCREW, OIL FILTER ADAPTOR (2	1		
9	10	91967	SCREW, OIL FILTER ADAPTOR	1		
10		91830	COVER, ADAPTOR	1		
11	22	15156	REDUCER	1		
12	22	46982	ELBOW	1		
13	87	14356	SWITCH, OIL PRESSURE	1		
14	32	92357 70	HOSE, OIL - ADAPTOR (45")	1	ALPHA I	
14	32	92357 9	HOSE, OIL - ADAPTOR (7")	1	ALPHA I	
14	32	92357 61	HOSE, OIL - ADAPTOR (36")	1	ALPHA I	
15	22	63825	FITTING, HOSE TO OIL COOLER	3	(90 DEGREES)	
16		89690T	OIL COOLER, ENGINE	1	ALPHA I	
17		63820 1	BRACKET, OIL COOLER (LONG)	1	ALPHA I	
18		56328A 1	BRACKET, OIL COOLER (SHORT)	1	ALPHA I	
19	10	60300	SCREW, OIL COOLER BRACKET	2	ALPHA I	
20	11	30506	NUT, OIL COOLER BRACKET SCF	2	ALPHA I	