



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		47735A 1	EXHAUST MANIFOLD ASSEMBLY	1		
1		47736A 1	EXHAUST MANIFOLD ASSEMBLY	1		
2	16	52988	STUD, EXHAUST MANIFOLD TI	8		
3	22	48118	PLUG, EXHAUST MANIFOLD	6		
4	22	32802	PLUG, PIPE - EXHAUST MANIF	2		
5	27	46820	GASKET, EXHAUST MANIFOLD T	2		8,1,2
6	10	37612	SCREW, EXHAUST MANIFOLD TI	8		
6	10	26486	SCREW, EXHAUST MANIFOLD TI	8		
7		60252	END CAP/CONNECTOR, EXHAUS	2		
8	27	48043	GASKET, END CAP/CONNECTOF	2		2
9	10	35386	SCREW, END CAP/CONNECTOR	6		
9	10	53016	SCREW, END CAP/CONNECTOR	2		
10		54870	END CAP, EXHAUST MANIFOLD I	2		
11	27	48043	GASKET, END CAP TO EXHAUST	2		2
12	10	25038	SCREW, END CAP TO EXHAUST	8		
13		48101A 4	EXHAUST EXHAUST ELBOW AS	4		
14	22	32802	PLUG, PIPE - EXHAUST ELBOW	2		
15	32	58616A 1	TUBE, WATER SEPARATION - I	2		
16	22	48118	PLUG, EXHAUST ELBOW	8		
17	27	48042	GASKET, EXHAUST ELBOW TO E	4		2
18		60390A 1	WATER DISTRIBUTION HOUSINI	1		
18		60391A 1	WATER DISTRIBUTION HOUSINI	1		
19	23	52020	SLEEVE, WATER DISTRIBUTIO	4		
20	22	32802	PLUG, PIPE - WATER DISTRIB	2		
21	13	37459	LOCKWASHER, EXHAUST ELBOW	8		
22	11	49838	NUT, EXHAUST ELBOW TO EXH	8		
23	32	46828	HOSE, THERMOSTAT HOUSING	1		
24	54	32781	CLAMP, HOSE TO THERMOSTAT	2		
25		59862A 1	THERMOSTAT HOUSING ASSEM	1		
26	23	47511	SLEEVE, THERMOSTAT HOUSI	1		
27	22	47540	PLUG, THERMOSTAT HOUSING	2		
28		47442	COVER, THERMOSTAT HOUSING	1		
29	27	48818	GASKET, THERMOSTAT HOUSIN	1		8,1
30		59137	THERMOSTAT	1		
31	27	53045	GASKET, THERMOSTAT HOUSIN	1		8,1
32	10	33389	SCREW, THERMOSTAT HSG. TO	2		
33	13	37459	LOCKWASHER, THERMOSTAT H	2		