

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		86247	FUEL PUMP ASSEMBLY	1	
2	10	35169	SCREW, FUEL PUMP TO CYLIND	2	
3	27	34213	GASKET, FUEL PUMP TO CYLINC	1	3
4		35377	ROD, PUSH - FUEL PUMP	1	
5	22	32876	NIPPLE, SIGHT GLASS TO FUEL	1	
6		47816	SIGHT GLASS	1	
7	35	60494A 5	FUEL FILTER	1	
8		89876	BASE, FUEL FILTER	1	
9	22	73379	PLUG, PIPE - FUEL FILTER	2	
10		54646	BRACKET, MOUNTING - FUEL FIL	1	
11	10	20639	SCREW, FUEL FILTER TO MOUN	2	
10		77453	BRACKET, MOUNTING - FUEL FIL	1	
11	10	26066	SCREW, FUEL FILTER TO MOUN	2	
12	12	20084	WASHER, FUEL FILTER SCREW	2	
13	11	35814	NUT, FUEL FILTER SCREW	2	
14	22	33821	ELBOW, FUEL LINE TO FUEL PUI	3	
15	32	62872	FUEL LINE, FUEL FILTER TO FUE	1	
16	32	62873	FUEL LINE< FUEL PUMP TO CAR	1	

