



| Parts List | | | | | | |
|------------|-------|---------|---------------------------------|-----|-----------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 97399A | 2 FUEL PUMP (AIRTEX) | 1 | | |
| 1 | | 812454A | 1 FUEL PUMP (CARTER) | 1 | | |
| 2 | 27 | 34213 | GASKET, FUEL PUMP TO CYLIND | 1 | | 2 |
| 3 | 10 | 37612 | SCREW, FUEL PUMP (1-1/4") | 2 | | |
| 4 | 13 | 35048 | LOCKWASHER, FUEL PUMP SCR | 2 | | |
| 5 | | 35377 | ROD, PUSH - FUEL PUMP | 1 | | |
| 6 | | 89876A | 3 BASE, FUEL FILTER | 1 | | |
| 7 | 22 | 73379 | PLUG, PIPE - FUEL FILTER (SLOT | 3 | | |
| 8 | 10 | 26066 | SCREW, FUEL FILTER TO MOUN | 2 | | |
| 9 | 11 | 35814 | NUT, FUEL FILTER SCREW | 2 | | |
| 10 | 35 | 60494 | 1 FUEL FILTER | 1 | | |
| 11 | 22 | 33821 | ELBOW, FUEL LINE TO FUEL PUI | 3 | | |
| 12 | 32 | 96082A | 1 FUEL LINE, FILTER TO PUMP | 1 | (Use with Airtex Fuel Pump) | |
| 12 | 32 | 19037T | 1 FUEL LINE, FILTER TO PUMP | 1 | (Use with Carter Fuel Pump) | |
| 13 | 32 | 96080 | 1 FUEL LINE, FUEL PUMP TO CAR | 1 | | |
| 14 | 32 | 73815 | 63 HOSE, PLASTIC - FUEL PUMP TO | 1 | | |