



A = See STARTER MOTOR AND ALTERNATOR ON Page 2 (Ref. #19)

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		16792A33	PUMP ASSEMBLY-POWER STEE	1		
2	16	41877	STUD	2		
3	36	95805	CAP	1		
4		807728T	PULLEY	1		
5		807751T	BRACE	1		
6	10	40001188	SCREW (M10 X 20)	3		
7	11	32219	NUT (3/8-16)	3		
8	11	90517	NUT	1		
9	32	806222 16	PRESSURE HOSE	1	(FITTINGS ON BOTH ENDS)	
10	25	89879	O-RING	1		
11	25	806232	O-RING	1		
12	32	806221 42	RETURN HOSE	1	(FITTING ON ONE END)	
13	25	89879	O-RING	1		
14	32	52519 14	HOSE-PUMP TO OIL COOLER	1		
15	54	815504105	CLAMP	3		