



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		861260	INJECTOR-FUEL	8		
2	25	851889	O-RING	16		2
3		861422A 5	INTAKE MANIFOLD	1		
4	27	807473A 1	GASKET SET	1		2
5	22	860075	PLUG-PIPE	3		
6	22	860266	VALVE-SCHRADER	1		
7	22	805515	CAP	1		
8	22	860265	FITTING-T	1		
9	10	808010	SCREW (5/16-18 X 1-3/8 IN.)	8		
10		861061T	FUEL RAIL	2		
11	10	86885	SCREW (1/4-20)	2		
12	16	845019	STUD	2		
13	22	93385	ELBOW	2		
14	32	861401	FUEL LINE-FUEL RAIL TO FUEL F	1		
15	32	861514	FUEL LINE-FUEL RAIL TO FUEL F	1		
16		861249	SENSOR-MAP	1		
17		861198	CLIP-MAP SENSOR	1		
18	10	823588	SCREW (#8-32 X 1/4 IN.)	1		
-	27	75611A98	GASKET SET-ENGINE OVERHAU	1		