



1802

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		862031T 1	ALTERNATOR ASSEMBLY, 65 Amp	1	SN# 0M320024 & Below	
1		863077T 1	ALTERNATOR, 65 Amp With 50mm	1	(Non Serviceable) SN# 0M320024	
2	11	40021 2	NUT, (M6)	2		
3	10	400011 34	SCREW, (M8 X 25)	1		
4	10	828213	SCREW, (.312-18 x 1.500)	2		
5	12	57792	WASHER	2		
6	11	859119	NUT, (.312-18)	2		
7		862055T	BRACKET, Alternator Mounting	1		
8	10	98261	SCREW, (.375-16 x .750)	2		
9	12	20084	WASHER, (.328 x .562 x .062)	1		
10		863443T 1	BRACKET	1	(Standard Cooling)	
10		863443T 3	BRACKET	1	(Closed Cooling)	1
11		862083T	BRACKET, Idler Adjusting	1		
12		818380T	BUSHING	1		
13	11	859135	NUT, (.437-20)	1		
14	43	818381 2	PINION STUD	1		
15		807757T	PULLEY (3.00 Inch Diameter)	1	SN# 0M320024 & Below	
15		864625T	PULLEY (4.25 Inch Diameter)	1	(With Power Steering) SN# 0M320024	
15		807757T	PULLEY (3.00 Inch Diameter)	1	(Compact Hydraulic Steering) SN# (
16	10	34353	SCREW, (.375-16 x 1.00)	2		
17		862082T	BRACE, Power Steering	1		
18	10	40001188	SCREW, (M10 x 20)	1		
19		864456T	BRACKET, Alternator Brace	1		
20	10	34353	SCREW, (.375-16 x 1.00)	1		
21		862085T	BRACE, Idler Bracket	1	(Bravo)	
22		818382	PULLEY	1	(Bravo)	
23		818380T	BUSHING	1	(Bravo)	
24	10	56393	SCREW, (.437-20 x 1.75)	1	(Bravo)	
25	11	859135	NUT, (.437-20)	1	(Bravo)	
26		862778	BRACKET, Alternator Brace	1		
27	10	34353	SCREW, (.375-16 x 1.00)	1		
28		806193A30	RESERVOIR, Drive Lube	1		
29	36	806727 1	CAP, Drive Lube Reservoir Bottle	1		
30	22	808624	CONNECTOR	1		
31		860065A 1	BRACKET KIT, Oil Bottle, Reservoir	1		
32		808023T	STRAP, Bracket, Retaining	1		
33	10	98261	SCREW, (.375-16 x .750)	3		
34	57	862086 1	BELT, Serpentine	1	(Alpha) (With Power Steering) SN#	
34	57	863876 4	BELT, Serpentine	1	(Alpha) (With Power Steering) SN#	
34	57	862088	BELT, Serpentine	1	(Alpha) (CHS And Non Power Steer	
34	57	862876 9	BELT, Serpentine	1	(Alpha) (CHS And Max Power Steer	