



**Parts List**

Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	863489	HOSE, Transmission Cooler To Che	1		
2	21	864206A	CHECK VALVE ASSEMBLY	1		
3	32	864480	HOSE, Check Valve To Tee Fitting	1		
4	32	864481	HOSE, T Fitting To Fuel Cooler	1		
5	32	863670	HOSE, Fuel Cooler To Water Distrib	1		1
6	32	863490	HOSE, Water Drain Accumulator T	1		1
7	22	864450	FITTING, Lower Distribution	1		1
8	32	863491	HOSE, Distribution Fitting To "Y" Fi	1		1
9	32	862274	HOSE, Lower Circulation Pump	1		1
10	32	863453	HOSE, Y Fitting To Circulating Pum	1		1
11	32	863465	HOSE, Drain Accumulator To Tee f	1		1
12	32	863496	HOSE, T Fitting To Port Elbow	1		1
13	32	863828	HOSE, T Fitting To Starboard Elbow	1		
14	32	863459	HOSE, Thermostat Housing To Star	1		
15	32	864393	HOSE, Thermostat Housing To Port	1		1
16	32	864477	HOSE, Sea Water Pump To "T" Fit	1		1
17	32	864478	HOSE, T Fitting To Trans Cooler	1		
18	22	862225	FITTING, Pushlock	4		1
19	32	862317	HOSE, Cylinder Block Drain To Dist	2	(Port-23.00 Inch) (Starboard-17 Inc	1
20	32	42850	HOSE, (44.00 Inches Bulk)	1	(Cut To Fit.)	1
21	25	62702	O-RING, (.301 x .070)	2		
22	22	863464A	FITTING	1		1
NS	23	864327	BUSHING, Oriface	1		1
NS	25	864353	O-RING	1		1
23	22	862993	FITTING	3		
24	54	815504212	CLAMP, Worm Gear, Hose	2		
25	54	815504216	CLAMP, Worm Gear, Hose	AR		
26	54	815504222	CLAMP, Worm Gear, Hose	2		
27	54	815504228	CLAMP, Worm Gear, Hose	1		
28	54	815504232	CLAMP, Worm Gear, Hose	AR		
29	22	862603	FITTING, Male Quick Connector (T	2		
30		863455	FITTING, Y	1		1
31	32	863343	HOSE, Sea Water Pump To Water	1		
32	22	861427	CAP	1		
33	22	861405	FITTING	1		
34	22	861406	SOCKET	1		
NS	19	807992	COVER, Hose Clamp End	AR		