



14628

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		66167A 2	BRACKET, Rear	2		
1		52158A20	BRACKET, Rear	2	(72C V-Drive And Remote V-Drive)	
2	10	37269	SCREW, (.437-14 x 2.00)	4		
2	10	47462	SCREW, (.437-14 x 1.250)	4	(72C V-Drive And Remote V-Drive)	
3	13	32993	LOCKWASHER, (.437)	4		
4	10	57357	SCREW, (.437-13 x 2.250)	2		
4	10	47724	SCREW, (.437-14 x 3.00)	2	(72C V-Drive And Remote V-Drive)	
5	54	47528	CLAMP, Mount Adjusting	4	(72C V-Drive And Remote V-Drive)	
6	13	32993	LOCKWASHER, (.437)	2		
7	11	29553	NUT, (.437-14)	2		
8		71128A 2	BRACKET	2		
9	10	68101	SCREW, (.375-16 x 1.375)	2		
10	16	805357	STUD, (.375-16 x 2.130)	4		
11	13	35048	LOCKWASHER, (.375)	4		
12	10	37269	SCREW, (.437-14 x 2.00)	2		
13	13	32993	LOCKWASHER, (.437)	2		
14	11	29553	NUT, (.437-14)	2		
15		66166A 4	TRUNNION	4		
16	13	68102	LOCKWASHER, (.750)	4		
17		66284A 2	BASE ASSEMBLY, Engine End	2		
18	11	20739	NUT, (.750-16), Jam	2		
19	14	66658	TAB WASHER	2		
20		816326A 2	BASE ASSEMBLY, Transmission End	2		
21	11	816331	NUT, (.750-16), Jam	2		
22	14	66658	TAB WASHER	2		
23	11	20739	NUT, (.750-16), Jam	4		
24	54	78945	J CLAMP, Harness Support	1		