



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		805597T	BRACKET (TRANSMISSION)	2		
2	10	37269	SCREW (2")	4		
3	13	32993	LOCKWASHER	4		
4	10	57357	SCREW (2-1/4")	2		
5	13	32993	LOCKWASHER	2		
6	11	29553	NUT	2		
7		71128A 2	BRACKET (ENGINE)	2		
8	10	68101	SCREW (1-3/8")	6		
9	13	35048	LOCKWASHER	6		
10	10	57357	SCREW	2		
11	13	32993	LOCKWASHER	2		
12	11	29553	NUT	2		
13		66166A 4	TRUNNION	4		
14	13	68102	LOCKWASHER	4		
15		66284A 2	BASE ASSEMBLY	2	ENGINE	
16	11	20739	JAM NUT	2	ENGINE	
17	14	66658	TAB WASHER	2	ENGINE	
18		816326A 2	BASE ASSEMBLY	2	TRANSMISSION	
19	11	816331	NUT	2	TRANSMISSION	
20	14	66658	TAB WASHER	2	TRANSMISSION	
21	11	20739	JAM NUT	4		