



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		47554	HOUSING, FLYWHEEL (DOUBLE	1		
2	22	48873	EXTENDER, OUTLET HOSE TO C	1		
3	22	48872	ELBOW, OUTLET HOSE (45 DEGI	1		
4	32	48944 1	HOSE, OUTLET - OIL COOLER TC	1		
5	22	48246	ELBOW, OUTLET HOSE TO CYLII	1		
6	22	48871	ELBOW, INLET HOSE TO OIL COI	1		
7	32	48946	HOSE, INLET - OIL COOLER TO C	1		
8	22	48246	ELBOW, INLET HOSE TO CYLINC	1		
9	22	48874	FITTING, REDUCER - INLET HOS	1		
10	38	47520	SERIAL PLATE	1		
11	10	20314	SCREW, SERIAL PLATE ATTACH	4		
12		47542	COVER, FLYWHEEL HOUSING	1		
13	10	28635	SCREW, COVER TO FLYWHEEL H	4		
14	13	26992	LOCKWASHER, COVER SCREW	4		
15	23	47511	SLEEVE, CONNECTING - FLYWHI	2		
16	22	32802	PLUG, DRAIN - FLYWHEEL HOU	1		
17	10	26632	SCREW, FLYWHEEL HOUSING T	1		
18	10	52708	SCREW, FLYWHEEL HOUSING T	4		
19	12	33181	WASHER, SEALING - FLYWHEEL	4		
20		47610	COOLER, OIL RIGHT SIDE	1		
21		47490	COVER, OIL COOLER RIGHT SID	1		
22	27	47495	GASKET, OIL COOLER COVER R	1		
20		47611	COOLER, OIL LEFT SIDE	1		
21		47541	COVER, OIL COOLER LEFT SIDE	1		
22	27	47496	GASKET, OIL COOLER COVER LI	1		
23	25	47632	"O" RING, SEALING - OIL COOLE	4		
24	11	47521	NUT, JAM - OIL COOLER	4		
25	22	47917	ELECTRODE, OIL COOLER	2		
26	10	20362	SCREW, OIL COOLER COVER TO	12		
27	12	36533	WASHER, OIL COOLER COVER S	4		
27	13	26993	LOCKWASHER, OIL COOLER COV	8		