


**BREAKDOWN
 OF WATER
 PUMP**



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1	46	58001A 4	WATER PUMP ASSEMBLY, COM	1			
2		47530	HUB, WATER PUMP PULLEY	1			
3		57967	SHAFT, WATER PUMP	1			
4	53	23720	RING, RETAINING - SHAFT AN	1			
5	30	20861	BALL BEARING, WATER PUMP	2			
6	26	23300	OIL SEAL, WATER PUMP SHAF	2			
7	26	58111	OIL SEAL, WATER PUMP SHAF	1			
8		47405	WEAR PLATE	2			
9		47529	INSERT, WATER PUMP	1			
10	47	47519	IMPELLER	1			
11	17	47526	PIN, IMPELLER DRIVE	1			
12		47497A 1	COVER ASSEMBLY, WATER PL	1			
13	23	47511	SLEEVE, WATER PUMP COVE	2			
14	27	47410	GASKET, WATER PUMP COVE	1			
15	10	28635	SCREW, WATER PUMP COVE	6			
16		52822	PULLEY, WATER PUMP	1			
17	10	20705	SCREW, WATER PUMP PULLEY	4			
18	13	39107	LOCKWASHER, WATER PUMP P	4			
19	32	47722A 1	HOSE, WATER PUMP TO OIL CO	1			
20	54	32780	CLAMP, HOSE TO WATER PUMP	2			
21	57	48121	BELT, WATER PUMP	1			
22		47489	BRACKET, WATER PUMP	1			
23	10	34354	SCREW, WATER PUMP BRACKE	1			
24	13	35048	LOCKWASHER, WATER PUMP B	1			
25	10	48948	SCREW, WATER PUMP BRACKE	1			
25	10	47461	SCREW, WATER PUMP BRACKE	1			
26	13	32993	LOCKWASHER, WATER PUMP B	2			
27	12	30315	WASHER, WATER PUMP BRACK	1			
28		47544	BRACE, WATER PUMP ADJUSTI	1			
29	10	34353	SCREW, ADJUSTING BRACE TO	1			
30	13	35048	LOCKWASHER, ADJUSTING BRA	1			
31	12	20553	WASHER, ADJUSTING BRACE SI	1			
32	10	35786	SCREW, ANJUSTING BRACE TO	1			
33	13	37449	LOCKWASHER, ADJUSTING BRA	1			
34	11	24883	NUT, ADJUSTING BRACE SCREW	1			