



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		805185A 27	DISTRIBUTOR ASSEMBLY	1		
2		815407A 2	CAP	1		
3	10	90926	SCREW	4		
4	27	805760	GASKET	1		
5		13524A 6	ROTOR/SENSOR WHEEL	1		
6	87	91019A 6	SENSOR ASSEMBLY	1		
7	10	66686	SCREW (1")	1		
7	10	72202	SCREW (1-1/4")	1		
8	43	818807	DRIVE GEAR	1		
9	17	47617	PIN	1		
9A	12	90931	WASHER	1		
10	27	34486 3	GASKET	1		
11		52185	CLAMP	1		
12	10	806681	SCREW (7/8")	1		
15	84	816761A16	SPARK PLUG WIRE KIT	1		
16	85	63709A 1	BOOT	8		
17	33	59571	SPARK PLUG	8		
18	392	805570A 2	IGNITION COIL	1		
19		65970T 1	BRACKET	1		
20	10	41408	SCREW (1-1/2")	1		
21	13	26996	LOCKWASHER	2		
22	11	68219	NUT (10-32)	2		
23	10	98261	SCREW	1		
24	13	35048	LOCKWASHER	1		
25	16	90096A 1	STUD ASSEMBLY	2		
26	54	72821	RETAINER	2		