



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		14957	OIL FILTER	1		
2		44393A 2	BRACKET, OIL FILTER	1		
3		32720	ADAPTOR	1		
4	32	92357 59	HOSE, OIL - ADAPTER TO BRACK	1		
5		90783A22	ADAPTER ASSEMBLY, OIL FILTE	1		
6		99889	VALVE, BY-PASS	1		
7		32720	ADAPTER	1		
8	22	37372	PIPE PLUG	1		
9	22	97368	ELBOW, OIL HOSE (90 )	2		
10		91830	COVER, ADAPTER	1		
11	27	91892	GASKET, ADAPTER COVER	2		2
12	10	91966	SCREW, OIL FILTER ADAPTER (4	1		
12	10	91967	SCREW, OIL FILTER ADAPTER (3	1		
13		63831A 3	OIL COOLER, ENGINE	1	WITHOUT POWER STEERING	
14	22	63825	ELBOW, ENGINE OIL COOLER (9)	2	WITHOUT POWER STEERING	
14		89690T	OIL COOLER, ENGINE	1	WITH POWER STEERING	
14	22	63825	ELBOW, ENGINE OIL COOLER (9)	1	WITH POWER STEERING	
14	22	48872	ELBOW, ENGINE OIL COOLER (4)	1	WITH POWER STEERING	
15		63820 1	BRACKET, OIL COOLER (LONG)	1		
16		56328A 1	BRACKET, OIL COOLER (SHORT)	1		
17	10	60300	SCREW, OIL COOLER BRACKET (3	2		
18	11	30506	NUT, OIL COOLER BRACKET SCF	2		
19	32	92357 69	HOSE, OIL - OIL COOLER TO BRA	1	W/O POWER STEERING	
20	32	92357 28	HOSE, OIL - OIL COOLER TO AD	1	W/O POWER STEERING	
19	32	92357 69	HOSE, OIL - OIL COOLER TO BRA	1	W/POWER STEERING	
20	32	92357 15	HOSE, OIL - OIL COOLER TO AD	1	W/POWER STEERING	