



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		12675A 7	FLYWHEEL HOUSING	1		
2		88791	RUBBER MOUNT	2		
3	23	99322	SPACER	2		
4	10	37612	SCREW (1-1/4 IN.)	4		
4	10	35870 1	SCREW (2 IN.)	1		
5	16	64066	STUD	2		
6	11	32219	NUT	2		
7	13	35048	LOCKWASHER	7		
8	12	20572	WASHER	1		
9		818719A 1	COVER ASSEMBLY	1		
10	10	32773	SCREW	7		
11	84	62826A 6	WIRE	1		