



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	628	6100	CONNECTING ROD ASSEMBLY	4		
2	10	75444	SCREW, CONNECTING ROD CAP	8		
3	11	64769	NUT, CONNECTING ROD CAP AT	8		
4		68704A 1	BEARING, CONNECTING ROD (S	4	WHEN ORDERING REPLACEME	
4		68704A 2	BEARING, CONNECTING ROD (.0	AR	WHEN ORDERING REPLACEME	
4		68704A 3	BEARING, CONNECTING ROD (.0	AR	WHEN ORDERING REPLACEME	
5	759	5920 10	PISTON ASSEMBLY (STD.)	4	WHEN ORDERING REPLACEME	
5	759	5920 11	PISTON ASSEMBLY (.005 O.S.)	AR	WHEN ORDERING REPLACEME	
5	759	5920 11	PISTON ASSEMBLY (.005 O.S.)	AR	WHEN ORDERING REPLACEME	
5	759	5920 12	PISTON ASSEMBLY (.030 O.S.)	4	WHEN ORDERING REPLACEME	
5	759	6610 10	PISTON ASSEMBLY (STD.)	AR	WHEN ORDERING REPLACEME	
5	759	6610 11	PISTON ASSEMBLY (.005 O.S.)	AR	WHEN ORDERING REPLACEME	
5	759	6610 12	PISTON ASSEMBLY (.030 O.S.)	AR	WHEN ORDERING REPLACEME	
6	39	75422	RING, PISTON (STD.)	4		
6	39	75423	RING, PISTON (.030 O.S.)	AR		
7	462	6102A 1	CAMSHAFT ASSEMBLY	1	SERIAL 00000000-05195053	
8	17	72511	PIN, CAMSHAFT	1	SERIAL 00000000-05195053	
7	462	7416	CAMSHAFT ASSEMBLY	1	SERIAL 05195054-09999999	
7A	28	86466	KEY, CAMSHAFT ASSEMBLY	1	SERIAL 05195054-09999999	
9	23	67484	BEARING, CAMSHAFT - OPTIONA	5	WHEN ORDERING REPLACEME	
10		72939	SHAFT, EXTENSION	1	SERIAL 00000000-05195053	
11		67492	THRUST PLATE, CAMSHAFT	1		
12	10	49668	SCREW, TRUST PLATE ATTACH	2		
13		68708	SPROCKET, CAMSHAFT	1	SERIAL 00000000-05189437	
13		86461	SPROCKET, CAMSHAFT	1	SERIAL 05189438-09999999	
14	10	70084	SCREW, SPROCKET TO CAMSH	3		
15		68717A 1	CHAIN, TIMING	1		
16		75202	TENSIONER, CHAIN	1		
17	23	75087	BUSHING, CHAIN TENSIONER	1		
18	10	75206	SCREW, CHAIN TENSIONER ATT	1		
19		56153	TAPPET	8		