



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	966	6187A 4	CYLINDER HEAD ASSEMBLY	1		
2	23	72119	SLEEVE, WATER	1		
3	19	74832	PLUG, CYLINDER HEAD	2		
4	10	67503	SCREW, CYLINDER HEAD ATTACHING	5		
5	10	72769	SCREW, CYLINDER HEAD ATTACHING	5		
6	17	67489	PIN, CYLINDER HEAD	2		
7	27	92166	GASKET, CYLINDER HEAD	1		1
8		67504	BALL UNIT, ROCKER COVER	8		
9		92966	ARM, ROCKER VALVE	8		
10	10	67506	SCREW, ROCKER ARM	8		
11	54	72531	LIFTING EYE	2		
12	10	48948	SCREW, LIFTING EYE - FRONT (7/16)	2		
13	13	32993	LOCKWASHER, LIFTING EYE SCREW	2		
16		67502 5	PUSH ROD, VALVE - STD	8		
16		67502 3	PUSH ROD, VALVE(.030 SHORTER)	AR		
16		67502 4	PUSH ROD, VALVE(.030 LONGER)	AR		
17		75414	VALVE, EXHAUST - STD.	4		
17		75415	VALVE, EXHAUST (.015 O.S.)	AR		
17		75416	VALVE, INTAKE - STD.	4		
17		75417	VALVE, INTAKE (.015 O.S.)	AR		
18	24	75411	VALVE SPRING	8		
19	26	75413	SEAL, VALVE STEM	8		
20		75412	RETAINER, VALVE SPRING	8		
21	28	56162	KEY, VALVE STEM	16		
22	32	74767	HOSE, CYLINDER HEAD TO EXHAUST	1		
23	54	32780	CLAMP, HOSE ATTACHING	2		
24		77681	ROCKER COVER	1		
25	36	75336	CAP, OIL FILTER	1		
26	10	35585	SCREW, ROCKER COVER ATTACHING	7		
27	13	22773	LOCKWASHER, ROCKER COVER	7		
28	27	73666	GASKET, ROCKER COVER	1		1