



| Parts List | | | | | | |
|------------|-------|----------|------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 71903A 2 | FRONT COVER ASSEMBLY | 1 | | |
| 2 | 26 | 89238 | SEAL, WATER PUMP | 2 | | |
| 3 | 26 | 67388 | SEAL, FRONT | 1 | | |
| 4 | 22 | 32802 | PIPE PLUG, DRAIN | 1 | | |
| 1 | | 88014A 2 | FRONT COVER ASSEMBLY | 1 | | |
| 2 | 26 | 89238 | SEAL WATER PUMP | 2 | | |
| 3 | 26 | 67388 | SEAL, FRONT | 1 | | |
| 4 | 22 | 32802 | PIPE PLUG, DRAIN | 1 | | |
| 8 | 10 | 35386 | SCREW, FRONT COVER TO CYLI | 5 | | |
| 9 | 12 | 20084 | WASHER, FRONT COVER TO CY | 5 | | |
| 8 | 10 | 35386 | SCREW, FRONT COVER TO CYLI | 6 | | |
| 9 | 12 | 20084 | WASHER, FRONT COVER TO CYL | 6 | | |
| 10 | 27 | 68714 | GASKET, FRONT COVER TO CYL | 1 | | 1 |
| 11 | 27 | 72099 | GASKET, IMPELLER COVER TO F | 1 | | 1 |
| 11 | 27 | 88046 | GASKET, IMPELLER COVER TO F | 1 | | 1 |
| 12 | 47 | 86462 | IMPELLER, WATER PUMP | 1 | | |
| 13 | 12 | 91863 | WASHER, IMPELLER SCREW | 1 | | |
| 14 | 13 | 21804 | LOCKWASHER, IMPELLER SCRE | 1 | | |
| 15 | 10 | 59645 | SCREW, IMPELLER ATTACHING | 1 | | |
| 16 | | 71902 | COVER, IMPELLER(L.H. ROTATIC | 1 | | |
| 16 | | 88013 | COVER, IMPELLER(R.H. ROTATIO | 1 | | |
| 17 | 10 | 67450 | SCREW, COVER TO CYLINDER B | 6 | | |
| 18 | 10 | 35386 | SCREW, IMPELLER COVER TO F | 4 | | |
| 19 | 12 | 20084 | WASHER, COVER ATTACHING S | 10 | | |
| 20 | | 71904 | COVER, WATER INLET (L.H. ROT | 1 | | |
| 18 | 10 | 74824 | SCREW, IMPELLER COVER TO F | 5 | | |
| 18 | 10 | 35386 | SCREW, IMPELLER COVER TO F | 4 | | |
| 19 | 12 | 20084 | WASHER, COVER ATTACHING S | 15 | | |
| 20 | | 88012 | COVER, WATER INLET (R.H. ROT | 1 | | |
| 21 | | 88045 | TIMING MARKER (R.H. ROTATIO | 1 | | |
| 22 | 10 | 55714 | SCREW, TIMING MARKER TO FR | 2 | | |
| 23 | 27 | 72098 | GASKET, WATER INLET COVER | 1 | | 1 |
| 24 | 10 | 28668 | SCREW, INLET COVER TO IMPEL | 3 | | |
| 25 | 12 | 21249 | WASHER, INLET COVER SCREW | 3 | | |