



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	50	69865	STARTER MOTOR ASSEMBLY, C	1,	
-	50	72550A 1	STARTER MOTOR ASSEMBLY, C	.1,	
-	50	88671A 1	STARTER MOTOR ASSEMBLY, C	.1,	
1	392	5720	MOTOR DRIVE (INCLUDES NU	1,	
1	392	6177	MOTOR DRIVE (INCLUDES NU	.1,	
1	392	8271	MOTOR DRIVE (INCLUDES NU	.1,	
2	392	5719	BEARING ASSEMBLY, INTERMI	1,1	
3	392	5721	PIN, MOTOR DRIVE	1,	
3	392	6178	PIN, MOTOR DRIVE	.1,	
4	392	5724	PLATE ASSEMBLY, DRIVE END	1,	
5	392	5725	BUSHING, DRIVE END PLATE	1,	
4	392	6180	PLATE ASSEMBLY, DRIVE END	.1,	
5	392	5725	BUSHING, DRIVE END PLATE	.1,	
6	392	5718	ARMATURE	1,	
6	392	6176	ARMATURE	.1,	
7	392	5730	PACKAGE, ARMATURE THRU	1,1	*
8	392	5722	FIELD ASSEMBLY	1,	
9	392	5731	BRUSH AND TERMINAL SET	1,	**
8	392	6179	FIELD ASSEMBLY	.1,	
8	392	8270	FIELD ASSEMBLY	.1,	
9	392	6181	BRUSH AND TERMINAL SET	.1,	FOOTNOTE APPLIES TO B-50-72**
10	392	5727	SPRING SET, BRUSH (2 SPRIN	2,2	
11	392	5726	BRUSH PLATE AND HOLDER A	1,1	
12	392	5728	TERMINAL STUD PACKAGE	1,1	
13	392	5723	END CAP ASSEMBLY, COMMU	1,1	
14	392	5729	BOLT, THRU - END CAP TO EN	2,2	