




BREAKDOWN OF WATER PUMP



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	72774A11	WATER PUMP ASSEMBLY	1		
1A	46	72774	BODY, WATER PUMP 1	1		
2		87631	COVER, WATER PUMP	1		
3	10	63328	SCREW, COVER TO BODY (3")	5		
4	12	20084	WASHER, COVER SCREW	5		
5	27	72779	GASKET, COVER TO OUTER W	1		
6		72777	WARE PLATE	1		
7	27	72780	GASKET, BODY TO WEAR PLA	2		
8	47	59362A 1	IMPELLER ASSEMBLY	1		
9	19	59504	PLUG, IMPELLER	1		
10	28	56662	KEY, IMPELLER DRIVE	1		
11		72778	WEAR PLATE	1		
12	25	37340	"O" RING, PUMP HOUSING TO	1		
13	46	71497A 2	PUMP HOUSING	1		
14	26	23300	OIL SEAL, WATER PUMP SH/	2		
15	30	72961	BALL BEARING, WATER PUM	2		
16		59501	SHAFT, WATER PUMP	1		
17	53	23720	RING, SNAP - BALL BEARING	1		
18	26	72785	OIL SEAL, WATER PUMP SH/	1		
19		47530	HUB, WATER PUMP PULLYE	1		
20		73798	PULLEY, WATER PUMP	1		
21		58265	CLAMPING RING, PUMP PULLEY	1		
22	10	47277	SCREW, PULLEY TO WATER PU	4		
23	13	39107	LOCKWASHER, WATER PUMP P	4		
24		78010	BRACKET, WATER PUMP	1		
25	10	34354	SCREW, WATER PUMP CRACKE	1		
26	13	35048	LOCKWASHER, WATER PUMP B	1		
27	16	57932	STUD, WATER PUMP BRACKET	1		
28	11	23161	LOCK NUT, WATER PUMP BRAC	1		
29	12	20553	WASHER, WATER PUMP BRACK	1		
30	16	57932	STUD, WATER PUMP BRACKET	1		
31	13	35048	LOCKWASHER, ADJUSTING BRA	1		
32	12	34714	WASHER, ADJUSTING BRACKET	1		
33	11	24883	NUT, ADJUSTING BRACKET STU	1		
34	57	74271	BELT, WATER PUMP	1		
35	22	32802	PLUG, PIPE (FOR WATER PUMP	1		
36	32	78108	HOSE, MOLDED - WATER PUMP	1		
37	54	32780	CLAMP, HOSE ATTACHING	2		